MAINTENANCE OF AIR SAMPLING PUMPS

Purpose

This Meteorology and Air Quality Group (MAQ) procedure describes the steps to rebuild, replace parts, perform preventive maintenance, test, and prepare new Gast vacuum pumps for service for the AIRNET monitoring system.

Scope

This procedure applies to the rebuilding, testing, preparation, and preventive maintenance performed on the air pumps used to sample air as part of the AIRNET project.

In this procedure

This procedure addresses the following major topics:

Topic	See Page
General Information About This Procedure	2
Who Requires Training to This Procedure?	2
Servicing a Pump	4
Preparing a New Pump for Service	8
Records Resulting from This Procedure	9

Signatures

Prepared by:	Date:
	12/08/05
Jake Martinez, MAQ	12/00/00
Approved by:	Date:
	12/12/05
Craig Eberhart, Environmental Air Monitoring Team Leader	12/12/00
Approved by:	Date:
·	12/08/05
Terry Morgan, QA Officer	12/00/00
Approved by:	Date:
	12/12/05
Dianne Wilburn, Acting MAQ Group Leader	12/12/00

01/03/06

General information about this procedure

Attachments

This procedure has the following attachments:

		No. of
Number	Attachment Title	pages
1	Exploded View of Pump and Parts	2

History of revision

This table lists the revision history and effective dates of this procedure.

Revision	Date	Description Of Changes			
0	12/18/95	New document.			
1	9/24/96	Added steps describing bearing replacement.			
2	7/16/97	Added more steps and details on power cord			
		installation and bearing replacement.			
3	1/25/99	Added caution about hearing damage and rules for			
		operating pumps inside Cave, requirement for wearing			
		steel-toed shoes when carrying pumps, and note on			
		bearing failures in Emerson motors.			
4	4/27/99	Added some steps and clarified other steps to add			
		more detail.			
5	12/14/04	Updated to refer to new IWD for pump rebuilding			
		work and minor changes to adjustment specifications.			
6	01/05/06	Removed obsolete text on bearing failures and bearing			
		types, other minor changes throughout.			

Who requires training to this procedure?

The following personnel require training before implementing this procedure:

MAQ employee assigned to perform pump maintenance

Training method

The training method for this procedure is on-the-job training conducted by a previously trained individual and is documented in accordance with the procedure for training (MAQ-024).

General information, continued

References

The following documents are referenced in this procedure:

- MAQ-011, "Logbook Use and Control"
- MAQ-024, "Personnel Training"

Note

Actions specified within this procedure, unless preceded with "should" or "may," are to be considered mandatory guidance (i.e., "shall").

Servicing a pump

pump

Description of The Gast vacuum pump model number 1023-101Q is an oil-less vane-type pump connected to a ¾ hp GE or Emerson electric motor.

Spare parts

Keep the following minimum inventory of parts on hand. Refer to the parts list in Attachment 1 for part numbers.

- 10 O-rings (part number 58075-2-126 [Parker] or part number AK473 [Gast])
- 50 filters (part number AK524)
- 10 gaskets (part number AK522)
- 100 vanes (part number AK513)
- 15 inner bearings by Fafnir (part number 205PP)
- 15 outer bearings by Fafnir (part number 203KDD)

Ordering spare parts

Order parts needed by calling the Gast Manufacturing service representative at 310-404-2721. Refer to the parts list in Attachment 1 for part numbers.

Number of spare pumps

In order to keep a sufficient number of pumps available for six-month replacement, keep a minimum of 20 serviced pumps on the shelf.

Required safety equipment

Wear steel-toed shoes <u>anytime</u> you are carrying or lifting pumps.

Servicing a pump, continued

Parts and equipment

Assemble the following parts and equipment before starting work on a pump:

- 1/4" or 3/8" drive socket set
- gasket scraper
- philips screwdriver
- straight screwdriver
- 9 piece open end wrench set
- feeler gauge set
- torque wrench (1/4" drive, reading to at least 100 inch-pounds)

If bearings are to be replaced:

- hydraulic press
- new bearings (#6205 and #6203)
- bearing heater

- 2 new o-rings
- 4 new pump vanes

2 new filters

- vacuum gauge
- safety glasses

new end shield plate

- tool tube (#777)
- temp-indicating marker

IWD requirements

Follow the safety requirements in the associate integrated work document (IWD) for this work.

Steps to rebuild pump

To rebuild the pump, perform the following steps:

Step	Action				
1	Remove the two end caps from the muffler box.				
2	Remove the filters from the end caps and replace with new filters.				
3	Remove muffler box from end plate; be careful not to damage gasket.				
4	Remove end plate from body.				
5	Remove shroud from electric motor.				
6	Remove four vanes from rotor; observe the orientation of the vane				
	contact surfaces for later reassembly.				
7	Clean all parts with Fantastic cleaner before reassembling.				
8	In the hood, blow dust from all parts with compressed air.				
	Wear safety glasses or keep hood door lowered to calibrated level.				
9	Check the condition of O-rings (on filters) and gaskets. Replace any				
	O-rings that exhibit faint cracks when gently bent or seem stiffer than				
	new O-rings. Replace gaskets that appear cracked.				
10	If the rotor is stiff to turn or if the bearing hours are between 12,000				
	and 15,000, remove the shaft and replace inner and outer bearings by				
	following steps 11 through 26.				
	If the bearings do not need to be replaced , go to step 26.				

Servicing a pump, continued

Step	Action
11	Remove the bolts holding the body using 3/16" allen wrench. Remove the body.
12	Remove the 4 through-bolts and the end shield from the electrical
	motor.
13	Remove the electrical motor shaft using a hammer and a 6" steel rod, making sure spring washers are kept in place. NOTE : If the spring washers are released, refer to Attachment 1 for proper reassembly.
14	Place motor shaft in the hydraulic press and remove the rotor using a 6" rod. Hold shaft while slowly pressing. Then remove the inner and outer bearings using the three-finger puller on the vise.
15	In the hood, blow dust from the rotor and the motor housing with compressed air. Wear safety glasses or keep hood door lowered to calibrated level.
16	CAUTION: Burns from heated bearing are possible.
10	Wear thermal gloves to handle bearing. Ensure wire guard is in place
	when heating bearing.
	Place new inner bearing (#6205) on bearing heater. Mark bearing side
	with chalk indicator. Leave bearing on heater until indicator chalk
	changes color to dark blue. Use thermal gloves to pick up bearing and
	quickly drop straight on shaft.
17	Turn motor shaft around and repeat step 18 to install outer bearing
10	(#6203). If bearing does not slide on, use press.
18	Place motor shaft back into electrical motor housing. Ensure the round shim springs under the outer bearing are re-installed properly.
19	Install a new end shield, the inside pump end-plate, and the four
	through-bolts. Install nuts.
20	Torque the through-bolts to 30 in-pounds.
21	Using a dial indicator mounted on a sleeve that can be attached to the shaft, check that the end plate is flat within 0.000" as the shaft is turned through one revolution. To adjust, tighten the through-bolt on the side of the plate that is high. If the tolerance cannot be obtained
	after torquing any bolts to a maximum of 50 in-pounds, loosen the bolts and insert a shim under the plate on the low side; this also may
22	require a new end shield.
22	Slip a new control ring onto shaft and place electrical motor housing onto shelf of hydraulic press
23	With the press, press rotor over control ring and into place on the shaft
	with a clearance of 0.002" and no more than 0.003" (check with feeler
	gauge) between rotor and bearing housing.

Servicing a pump, continued

Step	Action
24	Reattach body to electrical motor housing using the two allen-head
	bolts.
25	Adjust the top clearance (between rotor and body) to factory
	specifications (0.002" and no more 0.003") by a) loosening body bolts
	and b) lightly tapping on the pump body while turning the rotor. Turn
	the rotor and assure that all points on the rotor clear the body.
26	Replace the shroud, the carbon vanes, and the end plate (6 bolts)
	loosely.
27	Ensure the muffler housing gasket is installed straight and not pinched.
	Ensure the O-rings on the endcap make a good seal on muffler box.
	Torque the body, end plate, and muffler box bolts to 100 in-pounds.
20	Reinsert filters.
28	To ensure the reassembled pump was assembled correctly and that it
	will develop sufficient vacuum, connect the vacuum gauge to the inlet port and run the pump for a minimum of five minutes. Test pumps
	with new bearings for a minimum of 24 hours. Ensure the vacuum
	gauge maintains at least 21" of vacuum at the end of the test.
	gauge maintains at least 21° of vacuum at the end of the test.
	CAUTION : Operating the vacuum pumps inside the Cave for long
	periods may cause permanent hearing damage.
	Conduct long-term pump tests outdoors. Pumps may be operated
	<u>inside</u> the Cave building only for a maximum of two minutes during
	work hours OR overnight. At the start of each work day, turn off any
	operating pumps and run them outside the building, if needed.
29	If the pump fails the test, remove endplate and install new vanes. If
	endplate is scored, regrind or replace and have the bearings replaced as
	described in steps 11 through 25. Remove and inspect body; if scored,
	replace. Remove and inspect rotor; if scored, replace. Reassemble and
	re-test. If second test fails, scrap the pump.
30	Record in the pump log book and in the electronic database the
	identifier of the pump, the maintenance performed on it, and the date.
	Make all logbook entries in compliance with the procedure for
21	logbooks (MAQ-011).
31	Store pumps in the appropriate storage area (TA-54-1001).

Preparing a new pump for service

New pumps

When a new pump is received, it requires installation of supporting feet and power cord.

Steps to prepare a new pump

To prepare a new pump for first service, perform the following steps:

Step	Action					
1	Assign an identifier to the pump and mark the pump with the identifier.					
2	Install supporting feet and new vacuum fittings.					
3	Obtain power cord (16-3 AWG U-L) from Mesa equipment (or					
	subsequent supplier).					
4	Take off electrical cover plate from rear of motor and connect power					
	cord to motor. Refer to the low-voltage diagram on motor case.					
5	Using a volt-ohm meter, make sure motor is grounded. Test between					
	the ground prong on the plug and the motor case. If no reading is					
	obtained, check the ground connection on the pump.					
6	Connect vacuum gage to the inlet port and run the pump for a					
	minimum of five minutes. Ensure the vacuum gage reads at least 21"					
	of vacuum at the end of the test.					
	CAUTION : Operating the vacuum pumps inside the Cave may cause					
	long-term hearing damage.					
	Conduct long town grown tests outdoors. Drawns grow he are made					
	Conduct long-term pump tests outdoors. Pumps may be operated					
	inside the Cave building only for a maximum of two minutes during					
	work hours OR overnight. At the start of each work day, turn off any					
7	operating pumps and run them outside the building, if needed.					
/	If the pump fails the test, return pump to factory for servicing (Gast					
	Manufacturing Corp., 2300 Highway M-139, Benton Harbor, MI					
8	49023-0097; phone 616-926-6171).					
0	Record in the pump log book and in the electronic database the					
	identifier of the new pump, the preparation steps performed on it, and					
	the date. Make all logbook entries in compliance with the procedure for logbooks (MAQ-011).					
9						
)	Store pumps on the shelf in the appropriate storage area (TA-54-1001).					


Records resulting from this procedure

Records

The following records are generated as a result of this procedure:

 entries in pump log book and electronic database (book will be submitted pursuant to MAQ-011)

EXPLODED VIEW OF PUMP AND PARTS



Her. No.	Description	aty	0823-101	0823-101Q	10235101	1023-1010	1423-101	1423-101Q
1 • 2 3 4 • 5 • 6 • 7 • 8 9	Body Vane Shroud End Plate Gasket Muffler Box O-Ring Felt End Cap End Cap Asm	-@BBGB-M@@~	AK517 AK513 AK511 AK515A	AK517 AK513 AK511 AK514 AK522 AK520 AK473 AK524 AK510 AK626	AK518 AK513 AK511 AK515A	AK518 AK513 AK511 AK514 AK522 AK520 AK473 AK524 AK510 AK526	AL283 AL284 AL281 AK515A	AL283 AL284 AL281 AK514 AK522 AK520 AK473 AK524 AK510 AK526
11 12 13	Filter/Muffler Elbow Nipple Service Kin	1 1 2	AK840 K479A	AK840 K479	AK840 K479A	AK840 K479	AC432 BA206 BA714 K575A	AC432 BA206 BA714 K575A

Denotes parts included in a Service Kit. When corresponding or ordering parts, please give complete model and serial number.

FOR ORIGINAL EQUIPMENT MANUFACTURERS SPECIAL MODELS CONSULT YOUR LOCAL DISTRIBUTOR.

