

5. Electrical Conductivity Test

Soil samples for the electrical conductivity (EC) test are taken from the 0- to 3-inch depth. Bulked soil samples from across the field can be collected, and two subsamples can be taken for analysis (See Chapter 1, Sampling Guidelines). **Electrical conductivity, pH, and soil nitrate are all measured from the same soil subsample.**

Materials needed to measure electrical conductivity (EC):

- 1/8-cup (30 mL) measuring scoop
- 120-mL plastic containers with lid
- EC pocket meter (blue with black cap)
- squirt bottle
- calibration solution (0.01 M KCl)
- distilled water

Did You Know?

Excess salts in soil can be a detriment to plant health. Salts can also hamper water movement into the soil and increase the occurrence of surface compaction.

① **Extract Subsample**

The soil sample should be thoroughly mixed before taking a subsample. Measure a 1/8-cup level scoop subsample of soil and place it in the plastic container. If soil nitrates will be measured on this subsample (Chapter 7), weigh the subsample for a more accurate estimate of soil nitrates. Enter the subsample weight on the Soil Data worksheet.

② **Add Water to Subsample and Mix**

- Add 1/8-cup (30 mL) of distilled water to the container with the subsample. The resulting soil/water mixture equates to a 1:1 soil to water ratio on a volume basis.
- Put the lid on the container and shake vigorously about 25 times.

Calibration Tip: Make sure the EC meter is calibrated before making a measurement. See Appendix C for calibration instructions.



③ **Measure and Record EC (See Calibration Tip)**

- Open the container and insert the EC pocket meter into the soil-water mixture. Take the reading while the soil particles are still suspended in solution. To keep the soil particles from settling, stir gently with the EC pocket meter. Do not immerse the meter above the immersion level (See Appendix C, Figure 1c). Allow the reading to stabilize (stays the same for about 10 seconds).
- Enter the EC reading on the Soil Data worksheet in decisiemens per meter (dS/m). The DiST WP 4 meter gives readings directly in dS/m. For the Microsensor 4 meter, divide the reading by 10, and for the Microsensor 3 meter, divide the reading by 100 to get readings in dS/m.
- Save the soil-water mixture for the pH measurement (Chapter 6).

④ **Turn the meter off. Thoroughly rinse meter with distilled water and replace cap.**