Author: V. Morris

Microwave Radiometer Daily Operating Procedure

I. Purpose:

This document describes the daily maintenance and checks performed on the microwave radiometer at the TWP facilities and the AMF site.

II. Cautions and Hazards:

• Do not press on the white Teflon® window cover; it will rip.

III. Requirements:

- Spray bottle filled with distilled water
- Soft, lint-free towels or Kimwipes

IV. Procedure:

A. Steps:

- 1. Inspect the white Teflon® window cover for damage such as cuts, gouges, or holes. If the window is damaged, complete the site operations log and indicate type of damage; enter the time and date on the site operations log.
- 2. If water is standing on the Teflon window due to rain or dew, gently brush the water off using a soft, lint-free towel; note this action in the site operations log.

Note: It is not necessary to completely dry the window because the heated blower will dry it.

- 3. If the Teflon® window cover is dirty, wet it with distilled water from the spray bottle. If it is not dirty, proceed to step 6.
- 4. Wipe the window gently with soft paper towels; the Teflon cover does not need to be completely dry because the heater/blower will dry the rest.

Note: Do not press on the window cover; it will rip.

5. Repeat steps 1 and 2 of these procedures until the window is clean.

6. Check the functioning of the dew blower/heater fan.

Note: The blower should always run while the radiometer is turned on; if it is not, report this observation in the site operations log.

- Lightly touch the dew sensor on top of the microwave radiometer.
- Did a red LED (Light Emitting Diode) used to indicate that the heater is functioning turn on? Check "yes" or "no" on the checklist.
- 7. Check the functioning of the elevation mirror:
 - Listen to the elevation mirror turn inside the microwave radiometer; count the number of turns it makes per minute.
 - Did you hear six turns per minute? Check "yes" or "no" on the checklist. (If you hear six turns per minute, the mirror is working.)
- 8. If the sensing element is dry and it is not raining or foggy, the heater in the blower housing should be **OFF**. This can be checked by looking at the green LED on the blower assembly. If the heater is **ON**, the moisture detector may need adjusting. Refer to the diagnostic procedure on Moisture Diagnostic Procedures, **PRO(MWR)-003**.
- Similarly, if the sensing element is wet and humidity is near 100%, the LED on the blower housing should be **ON**; check this by looking at the green LED on the blower assembly. If the heater is **OFF**, the moisture detector may need adjusting. Refer to the diagnostic procedure on MWR Blower/Heater Diagnostics, **PRO(MWR)-002.**
- 10. Note the time of the cleanings and checks on the checklist.
- 11. Record the date, start time, end time, and any comments on the site operations form.

V. References:

1. "Instrument Operation and Maintenance Procedure Development Checklist," by J. Liljegren.

VI. Attachments:

None.