Troubleshooting TSI Image Display Problem

I. Purpose:

This procedure outlines steps to address a situation when the TSI does not display images.

II. Cautions and Hazards:

None.

III. Requirements:

None.

IV. Procedure:

A. Troubleshooting TSI Image Display Problem

1. Unplug the 10baseT connector (for the camera) inside the TST box. Wait for a few minutes.

2. Plug the 10baseT connector back.

    Note: This is to power cycle the camera only, NOT the whole TSI.

3. If following Steps 1 and 2 does not solve the problem immediately, leave the camera connected for a few hours to allow the TSI to get its battery voltage up.

4. Repeat Steps 1 and 2.

5. If repeating Steps 1 and 2 twice does not solve the problem, proceed with a full power cycle (see *PRO(TSI)-002*) as follows:

    a) Shut off the TSI main power switch. Wait 2 to 3 minutes until the TST gracefully shuts down.

    b) Unplug on of the battery terminals. Wait 5 minutes.

    c) Turn the main switch back on.

    d) Reconnect the battery terminal unplugged in Step b). Wait 5 minutes.

    e) Unplug the camera. Wait 5 minutes.

    f) Plug the camera back.

6. If following all of the above steps does not restore the TSI images on the display, contact TWPO for further instruction.

V.   References:

1.   Power Cycling TSI, PRO(TSI)-002.

VI.   Attachments:

None.