

Chapter 22
DIESEL PARTICULATE MATTER SAMPLING

Blank Page

| Table of Contents | Page |
|---|-------------|
| I. Diesel Particulate Matter (DPM) Sampling Equipment | 22 - 1 |
| A. DPM Cassette | 22 - 1 |
| B. Sampling Pump | 22 - 1 |
| C. DPM Sampling Train | 22 - 2 |
| II. Diesel Particulate Matter Sampling Procedures | 22 - 2 |
| A. Personal Samples | 22 - 2 |
| B. Sampling Time | 22 - 2 |
| C. Pre-survey Calibration of Sampling Pump | 22 - 3 |
| D. Control Filter | 22 - 3 |
| E. Assemble the Sampling Train | 22 - 3 |
| F. Instructions to the Miner | 22 - 4 |
| G. Attach the Sampling Train to the Miner | 22 - 4 |
| H. Collect the Sample | 22 - 5 |
| III. Post-Inspection Procedures | 22 - 7 |
| A. Review the DPM Sampling Field Notes | 22 - 7 |
| B. Post-survey Calibration of Sampling Pump | 22 - 7 |
| C. Cyclone Cleaning and Assembly | 22 - 7 |
| D. Transport the Samples for Analysis | 22 - 7 |
| IV. Exposure Determination | 22 - 8 |

Figures

| | |
|--|--------|
| Figure 22-1. DPM Cassette, Cyclone and Holder Assembly | 22 - 1 |
| Figure 22-2. DPM Sampling Train | 22 - 2 |

Blank Page

Chapter 22

DIESEL PARTICULATE MATTER SAMPLING

I. Diesel Particulate Matter (DPM) Sampling Equipment

- A. **DPM Cassette** - Diesel particulate samples must be collected with the diesel particulate sampler manufactured by SKC, Inc. This sampler uses a submicron impactor which has a cut point of 0.9 micrometer when the flow rate is 1.7 Lpm in conjunction with a cassette-mounted filter. Particles greater than 0.9 micrometer are impacted and removed from the sample. The sample is analyzed for elemental carbon using the NIOSH Analytical Method 5040. Figure 22-1 shows the DPM cassette, cyclone, and holder assembly.



Figure 22-1. DPM Cassette, Cyclone and Holder Assembly

- B. **Sampling Pump** - Flow for the sampling assembly can be induced by any of the pumps commonly used for respirable or total dust sampling. Pumps must be calibrated at 1.7 Lpm in accordance with the standard pump calibration procedures.

- C. **DPM Sampling Train** - The DPM sampling train consists of the standard 10-mm Dorr-Oliver cyclone and SKC DPM cassette, mounted in the MSA holder assembly, and a sampling pump. The only difference from the set-up for respirable dust sampling is that the vortex finder is inserted directly into the SKC sampler instead of being connected to the cassette with the plastic barrel connector. Figure 22-2 shows a typical DPM sampling train.

II. Diesel Particulate Matter Sampling Procedures

- A. **Personal Samples** - Personal samples should be collected to determine a miner's exposure to diesel particulate matter. For this type of sampling, the holder assembly (with DPM cassette and cyclone) is attached to the worker's lapel.



Figure 22-2. DPM Sampling Train

- B. **Sampling Time** - The standard requires that diesel particulate matter concentrations be expressed as average eight-hour full-shift equivalent concentrations (shift-weighted average). Samples should therefore be collected for the full shift. As with other particulate samples, a 480-minute time will be used to calculate the concentration of diesel particulate matter.

- C. Pre-survey Calibration of Sampling Pump** - Prepare and calibrate the sampling pump using the procedures in Chapter 4, Sampling Pumps, of the Metal and Nonmetal Health Inspection Procedures Handbook.
- D. Control Filter** - The DPM filter cassette contains a control filter, therefore a separate control filter should not be prepared.

NOTE: Record all information on the DPM Sampling Field Notes form. It is not necessary to fill out the Health Field Notes form when sampling for DPM.

E. Assemble the Sampling Train

1. Remove the cassette from the box. Do not use the cassette if it is damaged or past the expiration date.
2. Remove the plugs from the cassette and place them in a clean, convenient location.
3. Attach the cassette to the cyclone. Refer to Figures 22-1 and 22-2. When properly assembled, the cyclone will lock into the steel holder and the cyclone inlet will face forward.
4. Tighten the set screw on the lapel holder so that all fittings are tight and the cassette is secured.
5. When assembling and disassembling the DPM cassette and the MSA breastplate, check the following:
 - The parts fit tightly enough together that some resistance can be felt between the cyclone and the cassette and at the cassette connection to the steel outlet hose connector of the holder assembly.
 - Rotate the cassette to verify that the steel outlet hose connection rotates with the cassette.

Both of these tests indicate that the O-rings are in place and providing a leak-tight seal. This is especially important in the holder assembly since it is reused many times. The O-ring in the lower part of the cassette is part of the cassette.

6. With the tubing connected to the holder, attach the other end of the tubing to the sampling pump inlet. See Figure 22-2.

F. Instructions to the Miner

1. Explain to the miner what you are doing, what the sampling device does, and the reason for the sampling (*i.e.*, the hazard).
2. Instruct the miner not to remove the sampling pump or sampling train at any time or cover the sampler or cyclone inlet with a coat or anything else. If the miner does not spend the full shift in the work area, note the time spent elsewhere in the DPM field notes.
3. Instruct the miner not to bump, drop, abuse, or tamper with the sampling pump or sampling train.
4. Emphasize the need for the miner to continue to work in a routine manner and report to you any unusual occurrences, work conditions, or problems encountered during the sampling period.
5. Inform the miner when and where the sampler will be removed and that you will be checking the equipment throughout the shift.
6. When conducting diesel particulate matter sampling, instruct the miner not to invert the cyclone holder. If this occurs, it should be reported immediately to the inspector, recorded in the DPM field notes, and the sample should be voided.

G. Attach the Sampling Train to the Miner

1. Attach the sampling pump and sampling train to the miner in such a manner that it will not create a safety hazard to the miner or anyone else performing normal work activities. Clip, pin, or tape the tubing to the clothing in such a manner that it does not interfere with the miner's job performance and does not present a safety hazard (such as, tubing catching on moving machine parts or railings). If the miner is not wearing a shirt or belt, the inspector should provide a belt or vest to facilitate sampling.
2. Attach the sampler to the miner's clothing within the breathing zone. For diesel particulate sampling, attach the sampling train so that the cyclone's grit pot is on the bottom of the assembly. Be certain that the cyclone inlet is facing away from the body of the miner.

H. Collect the Sample

1. Start the sampling pump.
2. Record the following information on the DPM Sampling Field Notes form:
 - Time the sampling pump was started;
 - Pump and DPM cassette identification numbers;
 - Miner's name, job title, and work location(s);
 - Shift hours per day and days per week worked;
 - Any respirator worn or expected to be worn (brand, model, type of filters); and
 - Whether an acceptable respiratory protection program exists.
3. During each full-shift sample, the inspector must observe the miner being sampled as frequently as is necessary to determine that a representative sample is being conducted of the normal activities. Check the sampling pump and sampling train to make sure that the sampling pump is operating properly, and to make sure the tubing and connections are not leaking. Do not adjust the flow rate at any time during sampling. Record what tasks the miner has performed in the time between subsequent checks so that the completed DPM Sampling Field Notes form will describe the miner's full work shift. This requirement does not necessarily preclude the inspector from doing other inspection work while sampling.
4. Throughout the shift, record other pertinent information:
 - The quantity and velocity of ventilating air at the location where samples are collected;
 - Condition of ventilation control structures (stoppings, doors, brattices, etc.);
 - The type of DPM control devices being used and their condition;
 - Type of fuel, such as diesel or biodiesel, in use at the mine;
 - Fuel sulfur content;

- Type of fuel additives used at the mine;
 - Information on the diesel equipment used at the workplace sampled, including:
 - the company equipment number or serial number;
 - the condition of the equipment;
 - whether there is a planned maintenance program in place;
 - whether the engine emits black smoke during acceleration; and
 - whether there is a person authorized to maintain diesel equipment.
 - List other equipment that may contribute to the miner's DPM exposure.
5. Collect the sampling train from the miner.
- a. Turn off the sampling pump before removing the sampling train or pump.
 - b. Record the time that the pump was turned off.
 - c. Carefully remove the sampling train:
 - Keep the cyclone upright to prevent the non-respirable dust in the grit pot from falling back through the cyclone onto the filter.
 - Remove the filter cassette from the lapel holder and replace the cassette plugs. Place a sample seal on the filter cassette.
 - Record the sample number on the sample seal. Date and sign the sample seal.

III. Post-Inspection Procedures

- A. Review the DPM Sampling Field Notes form** - Check that all the necessary information is included on the DPM Sampling Field Notes form.
- B. Post-survey Calibration of Sampling Pump** - Check the sampling pump calibration using the procedures in Chapter 4 of the Metal and Nonmetal Health Inspection Procedures Handbook.
- C. Cyclone Cleaning and Assembly**
1. Unscrew the grit pot from the cyclone. Empty the grit pot by turning it upside down and tapping it gently on a solid surface.
 2. Gently wash cyclone, grit pot, and the vortex finder (cyclone cap) by agitating in warm soapy water or, preferably, wash in an ultrasonic bath. Do not insert anything which can score or scratch the inner lining walls of the cyclone (such as a pipe cleaner).
 3. Rinse thoroughly in clean water, shake off excess water, and set aside to dry before reassembly.
 4. Inspect the cyclone and filter holder parts for damage or excessive wear, for a loose coupler or vortex finder, and for scoring or rifling (which can trap respirable particles, preventing them from reaching the filter). Pay special attention to the top internal surfaces of the cyclone when inspecting for scoring and rifling. Replace defective parts.
 5. Reassemble the cyclone, vortex finder (cyclone cap), and grit pot.
- D. Transport the Samples for Analysis**
1. Complete the Request for Laboratory Analysis (MSHA Form 4000-29) for the samples taken. In Item No. 15 on the form, designate "R" for respirable samples. In Item No. 16, fill in the analysis desired, diesel (carbon). Sample cassettes from different lots, used on the same day, should be listed on separate Request for Laboratory Analysis (RLA) forms. Be sure to provide all the information the laboratory will need to fill out the Personal Exposure Data Summary (PEDS).
 2. Ship the Request for Laboratory Analysis form(s) with the samples to the MSHA laboratory.

IV. Exposure Determination

The laboratory will complete the analysis and return an Analytical Report that will include the concentration, concentration limit, error factor, and calculated enforcement concentration limit (concentration limit times error factor). A PEDS will also be generated as appropriate. For each sample, the corrected elemental carbon concentration will be reported. The formula the Laboratory uses for calculating diesel particulate concentration is:

$$\text{Carbon Concentration } (\mu\text{g}/\text{m}^3) = \frac{C(\mu\text{g}/\text{cm}^2) * A(\text{cm}^2) * 1,000 \text{ L}/\text{m}^3}{1.7 \text{ Lpm} * 480 \text{ min}}$$

Where:

C = The corrected Elemental Carbon (EC) concentration measured in the thermal/optical carbon analyzer.

A = The deposit area of the filter media used in the DPM cassette.

A citation for an overexposure to the DPM limit of 350 ug TC/m³ of air will be issued when the total carbon (TC=OC + EC) exceeds 350 ug/m³ of air x the error factor of 1.13 and when the elemental carbon (EC x 1.3) concentration exceeds 350 ug/m³ x the error factor of 1.11.