



U.S. Department
of Transportation

**Federal Aviation
Administration**

Advisory Circular

Subject: Change 11 to AIRPORT DESIGN

Date: 3/28/2007

AC No: 150/5300-13

Initiated by: AAS-100

Change: 11

1. PURPOSE. This Change clarifies the standard for the Runway Protection Zone (RPZ). Recently, there has been some confusion about the permissibility of vehicle parking in RPZs. The FAA adopted a prohibition against parking in the extended Runway Object Free Area (ROFA) in 1989. While the intent of the RPZ standard has always been to expand this prohibition to the central portion of the RPZ along its entire length, this intent was not entirely clear in the previous standard.

This Change also does the following—

- a. Updates the Table of Contents.
- b. Updates Figure 2-3.
- c. Makes an editorial correction to Table 3-3.

2. CHANGED TEXT. Changed text is indicated by vertical bars in the margins.

PAGE CONTROL CHART

Remove Pages	Dated	Insert Pages	Dated
ii-v	2/14/97	ii-xii	3/28/07
vi-ix	9/30/00		
x-xii	2/14/97		
13-14	9/29/06	13	3/28/07
		14	9/29/06
19-20	11/10/94	19	11/10/94
	9/29/06	20	3/28/07
26-1	9/29/06	26-1	3/28/07
26-2		26-2	9/29/06

David L. Bennett
Director of Airport Safety and Standards

This page intentionally left blank.

CONTENTS

Paragraph	Page
Chapter 1. REGULATORY REQUIREMENTS AND DEFINITION OF TERMS	
1. GENERAL	1
2. DEFINITIONS	1
3. RELATED/REFERENCED READING MATERIAL.....	3
4. AIRPORT REFERENCE CODE (ARC).....	5
5. AIRPORT LAYOUT PLAN	5
6. MODIFICATION OF AIRPORT DESIGN STANDARDS TO MEET LOCAL CONDITIONS	5
7. NOTICE TO THE FAA OF AIRPORT DEVELOPMENT.....	5
8. NOTICE TO THE FAA OF PROPOSED CONSTRUCTION	6
9. FAA STUDIES.....	6
10. FEDERAL ASSISTANCE	6
11. ENVIRONMENTAL ASSESSMENTS.....	6
12. STATE ROLE	6
13. LOCAL ROLE	6
14. to 199. RESERVED	6
Chapter 2. AIRPORT GEOMETRY	
200. INTRODUCTION	9
201. PRINCIPLES OF APPLICATION	9
202. RUNWAY LOCATION AND ORIENTATION	9
203. ADDITIONAL RUNWAYS	10
204. TAXIWAY SYSTEM	10
205. AIRPORT APRONS	10
206. SEPARATION STANDARDS	10
207. PARALLEL RUNWAY SEPARATION--SIMULTANEOUS VFR OPERATIONS.....	11
208. PARALLEL RUNWAY SEPARATION--SIMULTANEOUS IFR OPERATIONS	11
209. RUNWAY TO PARALLEL TAXIWAY AND TAXILANE SEPARATION.....	12
210. BUILDING RESTRICTION LINE (BRL)	12
211. OBJECT CLEARING CRITERIA	12
212. RUNWAY PROTECTION ZONE (RPZ).....	13
213. to 299. RESERVED	13
Chapter 3. RUNWAY DESIGN	
300. INTRODUCTION.....	21
301. RUNWAY LENGTH	21
302. RUNWAY WIDTH.....	21
303. RUNWAY SHOULDERS.....	21
304. RUNWAY BLAST PAD.....	21
305. RUNWAY SAFETY AREA (RSA).....	21
306. OBSTACLE FREE ZONE (OFZ).....	22
307. RUNWAY OBJECT FREE AREA	23
308. CLEARWAY STANDARDS.....	23
309. STOPWAY STANDARDS.....	23
310. RESCUE AND FIREFIGHTING ACCESS.....	24
311. to 399. RESERVED	24
Chapter 4. TAXIWAY AND TAXILANE DESIGN	
400. INTRODUCTION	33
401. DIMENSIONAL STANDARDS	33
402. TAXIWAY SHOULDERS.....	33
403. TAXIWAY SAFETY AREA (TSA).....	33
404. TAXIWAY AND TAXILANE OBJECT FREE AREA (OFA)	33
405. PARALLEL TAXIWAY.....	33
406. TAXIWAY INTERSECTIONS	34

407.	ENTRANCE TAXIWAYS	34
408.	BYPASS TAXIWAYS	34
409.	HOLDING BAYS.....	34
410.	TURNAROUNDS	34
411.	DUAL PARALLEL TAXIWAYS.....	34
412.	TAXIWAY BETWEEN PARALLEL RUNWAYS.....	35
413.	EXIT TAXIWAYS	35
414.	APRON TAXIWAYS AND TAXILANES.....	35
415.	END-AROUND TAXIWAYS	35
416. to 499.	RESERVED.....	38

Chapter 5. SURFACE GRADIENT AND LINE OF SIGHT

500.	INTRODUCTION	49
501.	BACKGROUND	49
502.	SURFACE GRADIENT STANDARDS	49
503.	LINE OF SIGHT STANDARDS.....	56
504. to 599.	RESERVED.....	56

Chapter 6. SITE REQUIREMENTS FOR NAVAID AND ATC FACILITIES

600.	GENERAL.....	59
601.	MICROWAVE LANDING SYSTEM	59
602.	INSTRUMENT LANDING SYSTEM.....	61
603.	NONDIRECTIONAL BEACON.....	63
604.	VERY HIGH FREQUENCY OMNIRANGE	64
605.	APPROACH LIGHTING SYSTEMS	64
606.	OMNIDIRECTIONAL APPROACH LIGHTING SYSTEMS.....	65
607.	LEAD-IN LIGHTING SYSTEMS	65
608.	AIRPORT ROTATING BEACONS	65
609.	AIRPORT TRAFFIC CONTROL TOWERS.....	65
610.	AIRPORT SURVEILLANCE RADAR	66
611.	AIRPORT SURFACE DETECTION EQUIPMENT	66
612.	RUNWAY VISUAL RANGE FACILITIES.....	66
613.	AUTOMATIC WEATHER OBSERVATION STATIONS (AWOS).....	66
614.	PHYSICAL SECURITY	67
615.	CABLE PROTECTION.....	67
616. to 699.	RESERVED.....	67

Chapter 7. RUNWAY AND TAXIWAY BRIDGES

700.	INTRODUCTION	69
701.	SITING PRECEPTS	69
702.	DIMENSIONS.....	69
703.	LOAD CONSIDERATIONS.....	69
704.	DECK DESIGN.....	69
705.	MARKING AND LIGHTING.....	69
706.	OTHER CONSIDERATIONS.....	69
707.	PASSENGER AND BAGGAGE TUNNELS	70
708. to 799.	RESERVED.....	70

Chapter 8. THE EFFECTS AND TREATMENT OF JET BLAST

800.	INTRODUCTION	77
801.	JET BLAST EFFECTS.....	77
802.	BLAST FENCES.....	77
803.	SHOULDERS AND BLAST PADS	78

Appendix 1. WIND ANALYSIS

1.	OBJECTIVE.....	87
2.	CROSSWINDS	87
3.	COVERAGE AND ORIENTATION OF RUNWAYS	87
4.	ASSEMBLING WIND DATA.....	87
5.	ANALYZING WIND DATA.....	88
6.	CONCLUSIONS	88
7.	ASSUMPTIONS	88
8.	COMPUTER WIND ANALYSIS.....	88

Appendix 2. RUNWAY END SITING REQUIREMENTS

1.	PURPOSE.....	100
2.	APPLICATION.....	100
3.	LIMITATIONS	100
4.	EVALUATION CONSIDERATIONS.....	100
5.	CLEARANCE REQUIREMENTS	101

Appendix 3. AIRPORT REFERENCE POINT

1.	DISCUSSION.....	109
2.	SAMPLE COMPUTATION	109
3.	ACCURACY	109

Appendix 4. COMPASS CALIBRATION PAD

1.	PURPOSE.....	111
2.	BACKGROUND	111
3.	APPLICATION	111
4.	DESIGN OF COMPASS CALIBRATION PAD.....	111
5.	LOCATION OF COMPASS CALIBRATION PAD.....	112
6.	CONSTRUCTION OF COMPASS CALIBRATION PAD.....	112
7.	VOR CHECKPOINT	113

Appendix 5. SMALL AIRPORT BUILDINGS, AIRPLANE PARKING, AND TIEDOWNS

1.	GENERAL	117
2.	TRANSIENT APRON	117
3.	APRON FOR BASED AIRPLANES.....	117
4.	TIEDOWNS	118
5.	OTHER CONSIDERATIONS	118
6.	HANGARS.....	118
7.	ADMINISTRATION BUILDING	118
8.	AIRPORT SURVEY	122
9.	BUILDING PLAN	122
10.	EXPANSION	122
11.	CIRCULATION.....	122
12.	WAITING ROOM.....	122
13.	MANAGER'S OFFICE	123
14.	EATING FACILITIES	123
15.	PUBLIC RESTROOMS	123
16.	ROADS AND AUTO PARKING	123

Appendix 6. METRIC CONVERSION AND TYPICAL AIRPORT LAYOUT PLAN

Appendix cancelled (pp. 125-130)

Appendix 7. AIRPORT LAYOUT PLAN COMPONENTS AND PREPARATION

Appendix cancelled (pp. 131-138)

Appendix 8. RUNWAY DESIGN RATIONALE

1.	SEPARATIONS	139
2.	OBSTACLE FREE ZONE (OFZ)	139
3.	RUNWAY SAFETY AREA	139
4.	RUNWAY OBJECT FREE AREA (ROFA)	139
5.	RUNWAY SHOULDERS AND BLAST PADS	140
6.	CLEARWAY	140
7.	STOPWAY	140
8.	RUNWAY PROTECTION ZONE (RPZ)	140

Appendix 9. TAXIWAY AND TAXILANE DESIGN RATIONALE

1.	INTRODUCTION	141
2.	BACKGROUND AND RATIONALE	141
3.	EXIT TAXIWAY LOCATION	142
4.	WINGTIP TRACE	146

Appendix 10. TAXIWAY FILLET DESIGN

1.	INTRODUCTION	149
2.	EXAMPLE NO. 1, JUDGMENTAL OVERSTEERING	150
3.	EXAMPLE NO. 2, MAINTAINING COCKPIT OVER CENTERLINE	150

Appendix 11. COMPUTER PROGRAM

1.	AIRPORT DESIGN (FOR MICROCOMPUTERS) VERSION 4.2	153
2.	HOW TO OBTAIN A COPY OF AIRPORT DESIGN (FOR MICROCOMPUTERS) VERSION 4.2	153
3.	REQUIREMENTS	153
4.	SETUP ON A MICROCOMPUTER	153
5.	RUN AIRPORT DESIGN PROGRAM	153
6.	HOT KEYS	153
7.	RUNWAY AND TAXIWAY WIDTH AND CLEARANCE STANDARD DIMENSIONS	154
8.	RECOMMENDED RUNWAY LENGTHS	154
9.	STANDARD WIND ANALYSIS	154
10.	TAXIWAY DESIGN	155
11.	AIRPORT CAPACITY AND DELAY FOR LONG RANGE PLANNING	156
12.	DECLARED DISTANCE LENGTHS	156
13.	INPUT AIRPLANE DATA AVAILABILITY	156

Appendix 12. AIRPLANE DATA

1.	BACKGROUND	165
2.	EXPLANATORY INFORMATION	166

Appendix 13. AIRPLANES ARRANGED BY AIRPLANEMANUFACTURER AND AIRPORT REFERENCE CODE

Section 1.	Alphabetical Listing (U.S. customary units)	251
Section 2.	Alphabetical Listing (SI units)	257
Section 3.	Listing Small Airplanes by Airport Reference Code (U.S. customary units)	263
Section 4.	Listing Large Airplanes by Airport Reference Code (U.S. customary units)	264
Section 5.	Listing Small Airplanes by Airport Reference Code (SI units)	269
Section 6.	Listing Large Airplanes by Airport Reference Code (SI units)	270

Appendix 14. DECLARED DISTANCES

- 1. APPLICATION 275
- 2. BACKGROUND 275
- 3. FAA APPROVAL FOR APPLYING DECLARED DISTANCES IN AIRPORT DESIGN 275
- 4. RUNWAY SAFETY AREA (RSA) AND RUNWAY OBJECT FREE AREA (ROFA) LENGTHS 276
- 5. RUNWAY PROTECTION ZONE (RPZ) LOCATION AND SIZE 276
- 6. CLEARWAY LOCATION 276
- 7. NOTIFICATION 276

Appendix 15. TRANSFER OF ELECTRONIC DATA

- 1. INTRODUCTION 283
- 2. BACKGROUND 283
- 3. DEFINITIONS 283
- 4. APPLICATION 283
- 5. CADD FILE DELIVERABLES 284
- 6. DATABASES DELIVERABLES 286
- 7. PHOTOGRAMMETRY DELIVERABLES 286
- 8. FEATURES AND OBJECTS CODE 287
- 9. MEDIA 289
- 10. FAA POINT OF CONTACT 289

Appendix 16. NEW INSTRUMENT APPROACH PROCEDURES

- 1. BACKGROUND 291
- 2. INTRODUCTION 291
- 3. ACTION 291
- 4. DEFINITIONS 291

Appendix 17. MINIMUM DISTANCES BETWEEN CERTAIN AIRPORT FEATURES AND ANY ON-AIRPORT AGRICULTURE CROPS (1 page).

Appendix 18. ACRONYMS (1 page).

Appendix 19. INDEX (4 pages).

Table	Page
1-1. Increases in airport design standards associated with an upgrade in the first component (aircraft approach category) of the airport reference code.....	7
1-2. Increases in airport design standards to provide for lower approach visibility minimums	8
2-1. Runway separation standards for aircraft approach categories A & B.....	14
2-2. Runway separation standards for aircraft approach categories C & D.....	15
2-3. Taxiway and taxilane separation standards	16
2-4. Runway protection zone (RPZ) dimensions	19
3-1. Runway design standards for aircraft approach category A & B visual runways and runways with not lower than 3/4-statute mile (1 200 m) approach visibility minimums	25
3-2. Runway design standards for aircraft approach categories A & B runways with lower than 3/4-statute mile (1 200 m) approach visibility minimums	26
3-3. Runway design standards for aircraft approach categories C & D.....	26-1
4-1. Taxiway dimensional standards.....	38
4-2. Taxiway fillet dimensions	40
4-3. Wingtip clearance standards.....	40
4-4. Visual screen height calculation formula (same elevation as runway).....	48-5
4-5. Visual screen height calculation formula (EAT below DER elevation) for Design Group III.....	48-6
4-6. Visual screen height calculation formula (EAT below DER elevation) for Design Group IV	48-7
4-7. Visual screen height calculation formula (EAT below DER elevation) for Design Groups V and VI	48-8
4-8. Visual screen vertical height calculation tables.....	48-9
4-9. Visual screen panel wind-loading deflection allowance	48-12
4-10. CIE chromaticity coordinate limits.....	48-12
4-11. Minimum reflection levels.....	48-13
A2-1. Approach/Departure Requirements Table	103
A9-1. Exit taxiway cumulative utilization percentages	142
A16-1A. Precision instrument approach requirements.....	292
A16-1B Approach procedure with vertical guidance (APV-RNP) approach requirements.....	293
A16-1C Nonprecision approach requirements	294
A16-2 Survey requirements for instrument approach procedures	295
A17-1. Minimum Distances Between Certain Airport Features and Any On-Airport Agriculture Crops	296

Figure	Page
2-1. Typical airport layout	17
2-2. Parallel runway separation.....	18
2-3. Runway protection zone.....	20
3-1. Runway safety area.....	27
3-2. Obstacle free zone (OFZ) for visual runways and runways with not lower than 3/4 statute mile (1 200 m) approach visibility minimums.....	28
3-3. Obstacle free zone (OFZ) for runways serving small airplanes exclusively with lower than 3/4-statute mile (1 200 m) approach visibility minimums	29
3-4. Obstacle free zone (OFZ) for runways serving large airplanes with lower than 3/4-statute mile (1 200 m) approach visibility minimums.....	30
3-5. Obstacle free zone (OFZ) for runways serving large airplanes with lower than 3/4-statute mile (1 200 m) approach visibility minimums and displaced threshold	31
3-6. Precision object free zone.....	32
3-7. Clearway.....	32-1
3-8. Stopway	32-2
4-1. Taxiway intersection details	39
4-2. Maintaining cockpit over centerline	41
4-3. Judgmental oversteering	42
4-4. Example of pavement fillet computer program printout.....	43
4-5. Entrance taxiway	44
4-6. Bypass taxiway.....	44
4-7. Dual parallel taxiway entrance	45
4-8. Typical holding bay configurations.....	46

4-9.	Taxiway turnaround	46
4-10.	Crossover taxiway	47
4-11.	Right-angled exit taxiway	47
4-12.	Acute-angled exit taxiway	48
4-13.	Example of acute-angled exit taxiway computer layout data page 1	48-1
4-14.	Example of acute-angled exit taxiway computer layout data page 2	48-2
4-15.	Typical end-around taxiway layout	48-3
4-16.	End-around taxiway visual screen width calculations	48-4
4-17.	Visual screen width calculation formula	48-5
4-18.	Examples of mounting screen to vertical column	48-10
4-19.	Examples of panel layout for 13-foot-high screen	48-11
4-20.	Diagonal stripe orientation	48-12
4-21.	Examples of frangibility connections	48-14
5-1.	Longitudinal grade limitations for aircraft approach categories A & B	50
5-2.	Transverse grade limitations for aircraft approach categories A & B	51
5-3.	Longitudinal grade limitations for aircraft approach categories C & D	52
5-4.	Transverse grade limitations for aircraft approach categories C & D	53
5-5.	Runway safety area grade limitations beyond 200 feet (60 m) from the runway end	55
5-6.	Runway visibility zone	57
6-1.	AZ antenna siting	59
6-2.	Typical NAVAID placement	60
6-3.	AZ antenna critical area	61
6-4.	EL antenna siting	61
6-5.	EL antenna critical area	61
6-6.	ILS LOC siting and critical area	62
6-7.	GS siting and critical area	62
6-8.	Marker beacon site	63
6-9.	NDB site	63
6-10.	A TVOR installation	64
7-1.	Full width runway-taxiway bridge	71
7-2.	Cross-section full width runway-taxiway bridge	72
7-3.	Minimum width taxiway bridge with positive edge protection, O'Hare Airport, Chicago, IL	73
7-4.	Example structural deck and depressed roadway, O'Hare Airport, Chicago, IL	74
7-5.	Suggested shoulder marking of minimum width taxiway bridge	75
7-6.	Controlled use service road, Los Angeles International Airport, Los Angeles, CA	76
8-1.	Velocity distance curves, DC-8	79
8-2.	Velocity distance curves, B-727	80
8-3.	Velocity distance curves, B-747	81
8-4.	Velocity distance curves, DC-10	82
8-5.	Blast velocities of business jet airplanes	83
8-6.	Typical blast deflector fences, metal	84
8-7.	Typical blast deflector fences, concrete	85
A1-1.	Wind vector diagram	89
A1-2.	Typical environmental data service wind summary	90
A1-3.	Windrose blank showing direction and divisions	91
A1-4.	Completed windrose using figure A1-2 data	92
A1-5.	Windrose analysis	93
A1-6.	Windrose analysis--estimating area not included	94
A1-7.	Computer printout page 1	95
A1-8.	Computer printout page 2	96
A1-9.	Computer printout page 3	97
A1-10.	Lotus cell-formulas page 1	98
A1-11.	Lotus cell-formulas page 2	99
A2-1.	Approach slopes	105
A2-2.	Approach slopes—with offset approach course	106
A2-3.	Departure surface for Instrument Runways TERPS (40:1)	107
A2-4.	One-Engine Inoperative (OEI) Obstacle Identification Surface (62.5:1)	108
A3-1.	Sample layout	109

A3-2.	Sample computation - airport reference point	110
A4-1.	Marking layout and details of wheel block	114
A4-2.	Type I. compass calibration pad	115
A4-3.	Type II. compass calibration pad	116
A5-1.	Parking apron area	119
A5-2.	Tiedown layouts	120
A5-3.	T-hanger layout	121
A8-1.	Approximate distance airplanes undershoot and overrun the runway end	140
A9-1.	Wingtip clearance - parallel taxiways	143
A9-2.	Wingtip clearance from taxiway	144
A9-3.	Wingtip clearance from apron taxiway	144
A9-4.	Wingtip clearance from taxilane	145
A9-5.	Pavement edge clearance on tangent	146
A9-6.	McDonnell-Douglas MD-88 wingtip clearance trace for a 100-foot (30.5 m) radius centerline	147
A9-7.	McDonnell-Douglas MD-88 wingtip clearance trace for a 120-foot (36.5 m) radius offset centerline	147
A9-8.	Boeing 727-200 wingtip clearance trace for a 120-foot (36.5 m) radius offset centerline	148
A9-9.	Boeing 727-100 wingtip clearance trace for a 120-foot (36.5 m) radius offset centerline	148
A10-1.	Taxiway intersection details	151
A10-2.	Depiction of symbols	152
A11-1.	THIS FIGURE INTENTIONALLY LEFT BLANK	156
A11-2.	Estimated airplane data elements for input in the computer program	157
A11-3.	Example of the airport design airplane and airport data window	158
A11-4.	Example printout of width and clearance standard dimensions page 1	158
A11-5.	Example printout of width and clearance standard dimensions page 2	159
A11-6.	Example printout of wind analysis (two bi-directional runways)	160
A11-7.	Example printout of windrose (two bi-directional runways)	161
A11-8.	Example printout of wind analysis (one uni-directional runway)	162
A11-9.	Example printout of windrose (one uni-directional runway)	163
A11-10.	Nomenclature used in the taxiway design task	164
A11-11.	Nomenclature used in the declared distance task	164
A12-1.	Single engine, high wing, tailwheel airplanes 8,000 lb. (3,628 Kg) or less	167
A12-2.	Single engine, high wing, tailwheel airplanes 8,000 lb. (3,628 Kg) or less (cont'd)	168
A12-3.	Single engine, high wing, tricycle gear airplanes 8,000 lb. (3,628 Kg) or less	169
A12-4.	Single engine, low wing, tricycle gear airplanes 8,000 lb. (3,628 Kg) or less	170
A12-5.	Single engine, low wing, tricycle gear airplanes 8,000 lb. (3,628 Kg) or less (cont'd)	171
A12-6.	Twin engine, low or mid wing, tricycle gear airplanes 8,000 lb. (3,628 Kg) or less	172
A12-7.	Twin engine, low or mid wing, tricycle gear airplanes 8,000 lb. (3,628 Kg) or less (cont'd)	173
A12-8.	Twin engine, high or mid wing, tricycle gear airplanes 8,000 lb. (3,628 Kg) or less	174
A12-9.	Aérospatiale Nord 262	175
A12-10.	Aérospatiale/Sud SE-210 Caravelle	176
A12-11.	Airbus Industries A300, 310, and 320	177
A12-12.	Avions de Transport Regional ATR-42 & -72	178
A12-13.	Avions Marcel Dassault Mystère 20 (Fan Jet Falcon)	179
A12-14.	BAe 1-11	180
A12-15.	B.A.C./SNIAS Concorde	181
A12-16.	B.A.C./Vickers VC-10	182
A12-17.	B.A.C./Vickers Viscount	183
A12-18.	Beech Starship	184
A12-19.	Beechcraft Airliner	185
A12-20.	Beechcraft King Air	186
A12-21.	Beechcraft Model 18 and Conversions	187
A12-22.	Beechcraft Queen Air	188
A12-23.	Boeing B-52 Stratofortress	189
A12-24.	Boeing KC-97L	190
A12-25.	Boeing KC-135A	191
A12-26.	Boeing 707-720	192
A12-27.	Boeing 727	193
A12-28.	Boeing 737	194

A12-29. Boeing 747	195
A12-30. Boeing 757	196
A12-31. Boeing 767	197
A12-32. British Aerospace 146	198
A12-33. Canadiar CL-44	199
A12-34. Canadiar CL-66	200
A12-35. Cessna Citation	201
A12-36. Construcciones Aeronauticas CASA C-212 and 235	202
A12-37. Convair-liner and Turboprop Conversions	203
A12-38. De Havilland Canada C-7 Caribou	204
A12-39. De Havilland Canada DASH 7 & DASH 8	205
A12-40. Douglas C-124 Globemaster	206
A12-41. De Havilland Canada DHC-6 Twin Otter	207
A12-42. Dornier Gmb H	208
A12-43. Douglas DC-3	209
A12-44. Douglas DC-4/6/7	210
A12-45. Embraer EmB 110	211
A12-46. Embraer EmB 120	212
A12-47. Fairchild C-119K Flying Boxcar	213
A12-48. Fairchild C-123K Provider	214
A12-49. Fairchild F-27	215
A12-50. Fokker F-27	216
A12-51. Fokker F-28	217
A12-52. Gates Learjet	218
A12-53. General Dynamics/Convair 880/990	219
A12-54. Grumman Gulfstream I	220
A12-55. Grumman Gulfstream II	221
A12-56. Grumman G-64/G-III	222
A12-57. Grumman G-73	223
A12-58. Hamburger-Flugzeugbau HFB-320 Hansa	224
A12-59. Hawker Siddeley DH. 104 Dove	225
A12-60. Hawker Siddeley DH. 114 Heron	226
A12-61. Hawker Siddeley HS-125	227
A12-62. Hawker Siddeley HS-748	228
A12-63. Ilyushin IL-62	229
A12-64. Israel Aircraft Industries Westwind	230
A12-65. Lockheed Constellation and Super Constellation	231
A12-66. Lockheed C-5B Galaxy	232
A12-67. Lockheed C-141 Starlifter	233
A12-68. Lockheed L-188 Electra II	234
A12-69. Lockheed L-100 Hercules	235
A12-70. Lockheed L-1011 Tristar	236
A12-71. Lockheed L-1329 Jetstar	237
A12-72. Martin 404	238
A12-73. McDonnell-Douglas DC-8	239
A12-74. McDonnell-Douglas DC-9 and MD-80	240
A12-75. McDonnell-Douglas DC-10	241
A12-76. McDonnell-Douglas MD-11	242
A12-77. Mitsubishi MU-2	243
A12-78. Nihon/N.A.M.C. YS-11A	244
A12-79. Rockwell International NA-265 Sabreliner	245
A12-80. SAAB SF 340	246
A12-81. Short Brothers	247
A12-82. Shorts SC. 5/10 Belfast	248
A12-83. Swearingen Merlin	249
A12-84. Swearingen Metro	250
A14-1. Takeoff run available (TORA)	277
A14-2. Takeoff distance available (TODA)	278

A14-3. Accelerate-stop distance available (ASDA)279
A14-4. Landing distance available (LDA)280
A14-5. Example of a runway extended to 7000 feet281
A14-6. Example of a runway with threshold displaced for runway safety area282

b. Recommendations. Other objects that are desirable to clear, if practicable, are objects that do not have a substantial adverse effect on the airport but, if removed, will enhance operations. These include objects in the controlled activity area and obstructions to air navigation that are not covered in paragraph 211.a, especially those penetrating an approach surface. On a paved runway, the approach surface starts 200 feet (61 m) beyond the area usable for takeoff or landing, whichever is more demanding. On an unpaved runway, the approach surface starts at the end of the area usable for takeoff or landing.

212. RUNWAY PROTECTION ZONE (RPZ). The RPZ's function is to enhance the protection of people and property on the ground. This is achieved through airport owner control over RPZs. Such control includes clearing RPZ areas (and maintaining them clear) of incompatible objects and activities. Control is preferably exercised through the acquisition of sufficient property interest in the RPZ.

a. Standards.

(1) RPZ Configuration/Location. The RPZ is trapezoidal in shape and centered about the extended runway centerline. The central portion and controlled activity area the two components of the RPZ (see Figure 2-3). The RPZ dimension for a particular runway end is a function of the type of aircraft and approach visibility minimum associated with that runway end. Table 2-4 provides standard dimensions for RPZs. Other than with a special application of declared distances, the RPZ begins 200 feet (60 m) beyond the end of the area usable for takeoff or landing. With a special application of declared distances, see Appendix 14, separate approach and departure RPZs are required for each runway end.

(a) The Central Portion of the RPZ. The central portion of the RPZ extends from the beginning to the end of the RPZ, centered on the runway centerline. Its width is equal to the width of the runway OFA (see Figure 2-3). Paragraph 307 contains the dimensional standards for the OFA.

(b) The Controlled Activity Area. The controlled activity area is the portion of the RPZ to the sides of the central portion of the RPZ.

(2) Land Use. In addition to the criteria specified in paragraph 211, the following land use criteria apply within the RPZ:

(a) While it is desirable to clear all objects from the RPZ, some uses are permitted, provided they do not attract wildlife (see paragraph 202.g., *Wildlife Hazards*, and Appendix 17 for dimensional standards), are outside of the Runway OFA, and do not interfere with navigational aids. Automobile parking facilities, although discouraged, may be permitted, provided the parking facilities and any associated appurtenances, in addition to meeting all of the preceding conditions, are located outside of the central portion of the RPZ. Fuel storage facilities may not be located in the RPZ.

(b) Land uses prohibited from the RPZ are residences and places of public assembly. (Churches, schools, hospitals, office buildings, shopping centers, and other uses with similar concentrations of persons typify places of public assembly.) Fuel storage facilities may not be located in the RPZ.

b. Recommendations. Where it is determined to be impracticable for the airport owner to acquire and plan the land uses within the entire RPZ, the RPZ land use standards have recommendation status for that portion of the RPZ not controlled by the airport owner.

c. FAA Studies of Objects and Activities in the Vicinity of Airports. The FAA policy is to protect the public investment in the national airport system. To implement this policy, the FAA studies existing and proposed objects and activities, both off and on public-use airports, with respect to their effect upon the safe and efficient use of the airports and safety of persons and property on the ground. These objects need not be obstructions to air navigation, as defined in 14 CFR Part 77. As the result of a study, the FAA may issue an advisory recommendation in opposition to the presence of any off-airport object or activity in the vicinity of a public-use airport that conflicts with an airport planning or design standard or recommendation.

213. to 299. RESERVED

Table 2-1. Runway Separation Standards for aircraft approach categories A & B

ITEM	DIM <u>1/</u>	AIRPLANE DESIGN GROUP				
		I <u>2/</u>	I	II	III	IV
<i>Visual runways and runways with not lower than 3/4-statute mile (1200 m) approach visibility minimums</i>						
<i>Runway Centerline to:</i>						
Parallel Runway Centerline	H		- Refer to paragraphs 207 and 208 -			
Holdline			- Refer to Advisory Circular 150/5340-1 -			
Taxiway/Taxilane Centerline <u>3/</u>	D	150 ft 45 m	225 ft 67.5 m	240 ft 72 m	300 ft 90 m	400 ft 120 m
Aircraft Parking Area	G	125 ft 37.5 m	200 ft 60 m	250 ft 75 m	400 ft 120 m	500 ft 150 m
Helicopter Touchdown Pad			- Refer to Advisory Circular 150/5390-2 -			
<i>Runways with lower than 3/4-statute mile (1200 m) approach visibility minimums <u>4/</u></i>						
<i>Runway Centerline to:</i>						
Parallel Runway Centerline	H		- Refer to paragraphs 207 and 208 -			
Holdline			- Refer to Advisory Circular 150/5340-1 -			
Taxiway/Taxilane Centerline <u>3/</u>	D	200 ft 60 m	250 ft 75 m	300 ft 90 m	350 ft 105 m	400 ft 120 m
Aircraft Parking Area	G	400 ft 120 m	400 ft 120 m	400 ft 120 m	400 ft 120 m	500 ft 150 m
Helicopter Touchdown Pad			- Refer to Advisory Circular 150/5390-2 -			

1/ Letters correspond to the dimensions on Figure 2-1.

2/ These dimensional standards pertain to facilities for small airplanes exclusively.

3/ The taxiway/taxilane centerline separation standards are for sea level. At higher elevations, an increase to these separation distances may be required to keep taxiing and holding airplanes clear of the OFZ (refer to paragraph 206).

4/ For approaches with visibility less than 1/2-statute miles, runway centerline to taxiway/taxilane centerline separation increases to 400 feet (120 m).

Table 2-4. Runway protection zone (RPZ) dimensions

Approach Visibility Minimums <u>1/</u>	Facilities Expected To Serve	Dimensions			
		Length L Feet (meters)	Inner Width W ₁ feet (meters)	Outer Width W ₂ feet (meters)	RPZ acres
Visual And Not lower than 1-Mile (1 600 m)	Small Aircraft Exclusively	1,000 (300)	250 (75)	450 (135)	8.035
	Aircraft Approach Categories A & B	1,000 (300)	500 (150)	700 (210)	13.770
	Aircraft Approach Categories C & D	1,700 (510)	500 (150)	1,010 (303)	29.465
Not lower than $\frac{3}{4}$ -Mile (1 200 m)	All Aircraft	1,700 (510)	1,000 (300)	1,510 (453)	48.978
Lower than $\frac{3}{4}$ -Mile (1 200 m)	All Aircraft	2,500 (750)	1,000 (300)	1,750 (525)	78.914

1/ The RPZ dimensional standards are for the runway end with the specified approach visibility minimums. The departure RPZ dimensional standards are equal to or less than the approach RPZ dimensional standards. When a RPZ begins other than 200 feet (60 m) beyond the runway end, separate approach and departure RPZs should be provided. Refer to Appendix 14 for approach and departure RPZs.




Figure 2-3. Runway protection zone

Table 3-3. Runway design standards for aircraft approach categories C & D

ITEM	DI M <u>1/</u>	AIRPLANE DESIGN GROUP					
		I	II	III	IV	V	VI
Runway Length	A	- Refer to paragraph 301 -					
Runway Width	B	100 ft	100 ft	100 ft <u>2/</u>	150 ft	150 ft	200 ft
		30 m	30 m	30 m <u>2/</u>	45 m	45 m	60 m
Runway Shoulder Width <u>3/</u>		10 ft	10 ft	20 ft <u>2/</u>	25 ft	35 ft	40 ft
		3 m	3 m	6 m <u>2/</u>	7.5 m	10.5 m	12 m
Runway Blast Pad Width		120 ft	120 ft	140 ft <u>2/</u>	200 ft	220 ft	280 ft
		36 m	36 m	42 m <u>2/</u>	60 m	66 m	84 m
Runway Blast Pad Length		100 ft	150 ft	200 ft	200 ft	400 ft	400 ft
		30 m	45 m	60 m	60 m	120 m	120 m
Runway Safety Area Width <u>4/</u>	C	500 ft	500 ft	500 ft	500 ft	500 ft	500 ft
		150 m	150 m	150 m	150 m	150 m	150 m
Runway Safety Area Length Prior to Landing Threshold <u>5/</u> , <u>6/</u>		600 ft	600 ft	600 ft	600 ft	600 ft	600 ft
		180 m	180 m	180 m	180 m	180 m	180 m
Runway Safety Area Length Beyond RW End <u>5/</u> , <u>6/</u>	P	1,000 ft	1,000 ft	1,000 ft	1,000 ft	1,000 ft	1,000 ft
		300 m	300 m	300 m	300 m	300 m	300 m
Obstacle Free Zone Width and Length		- Refer to paragraph 306 -					
Runway Object Free Area Width	Q	800 ft	800 ft	800 ft	800 ft	800 ft	800 ft
		240 m	240 m	240 m	240 m	240 m	240 m
Runway Object Free Area Length Beyond RW End <u>7/</u>	R	1,000 ft	1,000 ft	1,000 ft	1,000 ft	1,000 ft	1,000 ft
		300 m	300 m	300 m	300 m	300 m	300 m

1/ Letters correspond to the dimensions on figures 2-1 and 2-3.

2/ For Airplane Design Group III serving airplanes with maximum certificated takeoff weight greater than 150,000 pounds (68,100 kg), the standard runway width is 150 feet (45 m), the shoulder width is 25 feet (7.5 m), and the runway blast pad width is 200 feet (60 m).

3/ Design Groups V and VI normally require stabilized or paved shoulder surfaces.

4/ For Airport Reference Code C-I and C-II, a runway safety area width of 400 feet (120 m) is permissible.

5/ The runway safety area (RSA) length begins at each runway end when a stopway is not provided. When a stopway is provided, the length begins at the stopway end.

6/ The standard RSA length beyond the runway end may be reduced to the standard RSA length prior to landing threshold if a standard Engineered Materials Arresting System (EMAS) is provided. To qualify for this reduction, the EMAS installation must provide the ability to stop the critical aircraft exiting the end of the runway at 70 knots, and the runway must provide either instrument or visual vertical guidance for approaches in the opposite direction. See AC 150/5220-22.

7/ The runway object free area length beyond the end of the runway never exceeds the standard RSA length beyond the runway end as provided by note 6 above.

This page intentionally left blank