


**PROPOSED CLEANUP
GUIDELINES for
SMALL CRUDE OIL SPILLS
using
BIOREMEDIATION
(PROCESS SELECTION FLOW CHART)***

James Brown, Lockheed Martin/REAC
Harry Allen, USEPA/ERT

***Prerequisites for Acceptance by Small Independent Oil Producers are that Guidelines be
SIMPLE, EFFECTIVE & LOW COST**



Type of Treatment


Ex-Situ Bioremediation

using a Small

Consolidated


Treatment Cell





How Clean is Clean?

- ❖ Absence of Petroleum Odor?
- ❖ 1% Petroleum Hydrocarbons?
- ❖ 1000 mg/kg Petroleum Hydrocarbons?
 - ❖ State ARARs
- ❖ Removal of Carcinogenic PAHs
(4-6 Ring PAHs Absent)




Site Selection

(Requires Tech. Support)

Select a Moderately Well Drained, Accessible Site at Least 300 Feet from the Nearest Potable Water Supply Well, and 100 Feet from the Nearest Surface Water.

**The Required Area is Proportional to the Volume of Petroleum-Contaminated Soil to be Treated
(2,000 ft² average)**






Soil Excavation & Consolidation

**Excavate Petroleum-Contaminated Soil &
Transport to the Consolidated Treatment Cell.
Cover soil prior to treatment to prevent loss of
VOCs.**





Treatment Cell Construction

(requires tech. support)

- ❖ break up subgrade surface to prevent compaction
- ❖ add 2 inches of composted hardwood bark or chopped hay/straw
- ❖ add 500 lb finely pulverized agricultural limestone per 1,000 ft² (12 Ton/Ac)
- ❖ add 2 inches of sand (or clean soil, sandy loam or coarser (USDA))





Treatment Cell Construction

(continued)

- ❖ add 2 inches of petroleum-contaminated soil/sediment
- ❖ add 1/4 of total N + all required P & K, based on a C:N:P:K ratio of 50:1:0.2:0.1 and 75% C in petroleum residues
- ❖ rototill until soil and bulking agents are well blended (6-7 times)





Select a Preferred Treatment Option

❖ Active Land Treatment
(weekly tillage)


(or)

❖ Phased Treatment
(2 months weekly tillage, then seeded to TPH tolerant
grasses)

(or)

❖ Passive Treatment, seeded to TPH tolerant grasses






O & M Requirements

❖ Add N Fertilizer Monthly

❖ Till to a full 6-inch
working depth






Treatment Cell Reuse


- ❖ Use one half the original TPH loading
- ❖ Soil quality improves with time
- ❖ Cell can be reused indefinitely






Assumptions

- ❖ **Initial Soil TPH**
4 to 6% (est.)
- ❖ **Estimated Time for Treatment**
About 1 Year
(based on 1 full-scale field study)
- ❖ **How Clean is Clean? – Absence of
Petroleum Odor After 4 Months**




Allegheny, New York Site

- ❖ Develop Simple, Effective, Low-Cost Bioremediation/Phytoremediation Methods to Independent Oil Producers for Treatment of Small Crude Oil Spills



Objectives – Allegany, New York Site


- ❖ Field Testing of Proposed Guidelines
- ❖ Treatment Effectiveness Comparison



Adverse Effects of Petroleum Hydrocarbons on Soil Quality


❖ Soil Effects

- ❖ Hydrophobic
- ❖ Degraded structure and consistence
- ❖ Poor aeration
- ❖ Reduced pH and nutrient buffering




Soil Quality Improvement

- ❖ Avoid compacting treatment cell surface/loosen if required
- ❖ Add large quantity of bulking agents (1:1 ratio or more)
- ❖ Add large quantity of limestone (10 tons/acre 6 inches)
- ❖ Add fertilizer to attain C:N of 40:1 using Monthly Additions -
Avoid High Soil Salinity




NY and PA Crude Oil Highly Treatable by Bioremediation

- ❖ 93% n-alkanes
- ❖ 90% TPH removal in 5-month treatability study




Regional & Soil Limitations

- ❖ 4-month treatment season
- ❖ fine textured soil
- ❖ poor drainage




Requirements for Success

- ❖ DRAINAGE
- ❖ Soil Quality Improvement (SQI)




Treatments Tested in 2004/2005

- ❖ Active land treatment
- ❖ Phased treatment
- ❖ Passive treatment with vegetative cover




Treatment Effectiveness Comparison

- ❖ 2-Year Field Test (2004/2005)
- ❖ Experimental design - randomized block design/4 blocks
- ❖ First Year/Results
 - 3.2% TPH \rightarrow $< 1\%$
 - No significant difference between treatments




Guidelines for Independent Oil Producer Cleanups

- ❖ **MUST BE:**
 - ❖ SIMPLE
 - ❖ EFFECTIVE
 - ❖ LOW COST




Initial Soil Stockpiles September 2003






Weathered Hay as Bulking Agent






Loosening Compacted Subgrade






Liming






Treatments October 2003






Mulched Surface (Piezometer in Foreground)






Treatment Cell Construction Issues: (do it right the first time)

- ❖ Some construction management required
- ❖ Raised sand bed for poorly drained sites
- ❖ Bulking agent [1/3 vol] - commercial compost (\$) vs grass hay (binds on tiller)
- ❖ Blended on-site soil (stony) vs sand (\$) [1/3 vol]




Monitoring?

- ❖ TPH in soil VOCs in groundwater (state issue)




Piezometer for BTEX Monitoring





Preferred Treatment? Based on Cost + Labor vs Rate of Treatment

- ❖ **Passive, vegetated = low cost; low labor**
- ❖ Active = higher cost; higher labor
- ❖ Phased Treatment = Moderate cost and labor
- ❖ Rate of Treatment – No difference after 1 year



End of Year 1 – October 2004






October 2004




TPH Tolerant Grasses:

- annual ryegrass
- perennial ryegrass
- tall fescue


File : I:\DATA\022705\KLM0106.D
Operator : SysLn
Acquired : 28 Feb 1996 10:50 am using AcqMethod QCCL1706
Instrument : 5972 Slic
Sample Name : 041-0008 Std
Misc Info : REAC 4 5858
Vial Number: 3





Time to Attain 1% TPH Endpoint?

- ❖ 1 year - 2004
- ❖ Reuse indefinitely if soil TPH is
1% to 2%



Treatment Cell Reuse Benefits

- ❖ Low Cost
- ❖ Soil Quality Improved
- ❖ Increased Soil Organic Matter
 - ❖ Improved structure, aeration, permeability
 - ❖ Improved drainage with time