§215.109

- (a) A plain bearing box that does not contain visible free oil;
- (b) A plain bearing box lid that is missing, broken, or open except to receive servicing; or
- (c) A plain bearing box containing foreign matter, such as dirt, sand, or coal dust, that can reasonably be expected to—
 - (1) Damage the bearing; or
- (2) Have a detrimental effect on the lubrication of the journal and the bearings.

§215.109 Defective plain bearing box: Journal lubrication system.

A railroad may not place or continue in service a car, if the car has a plain bearing box with a lubricating pad that—

- (a) Has a tear extending half the length or width of the pad, or more;
- (b) Shows evidence of having been scorched, burned, or glazed;
- (c) Contains decaying or deteriorated fabric that impairs proper lubrication of the pad;
 - (d) Has-
- (1) An exposed center core (except by design); or
- (2) Metal parts contacting the journal; or
 - (e) Is-
 - (1) Missing; or
 - (2) Not in contact with the journal.

§215.111 Defective plain bearing.

A railroad may not place or continue in service a car, if the car has a plain bearing—

- (a) That is missing, cracked, or broken:
- (b) On which the bearing liner—
- (1) Is loose: or
- (2) Has a broken out piece; or
- (c) That shows signs of having been overheated, as evidenced by—
 - (1) Melted babbitt;
 - (2) Smoke from hot oil; or
- (3) Journal surface damage.

\$215.113 Defective plain bearing wedge.

A railroad may not place or continue in service a car, if a plain bearing wedge on that car is—

- (a) Missing:
- (b) Cracked;
- (c) Broken; or

(d) Not located in its design position.

§215.115 Defective roller bearing.

- (a) A railroad may not place or continue in service a car, if the car has—
- (1) A roller bearing that shows signs of having been overheated as evidenced by—
 - (i) Discoloration; or
- (ii) Other telltale signs of overheating such as damage to the seal or distortion of any bearing component;
 - (2) A roller bearing with a-
 - (i) Loose or missing cap screw; or
- (ii) Broken, missing, or improperly applied cap screw lock; or
- (3) A roller bearing with a seal that is loose or damaged, or permits leakage of lubricant in clearly formed droplets.
- (b)(1) A railroad may not continue in service a car that has a roller bearing whose truck was involved in a derailment unless the bearing has been inspected and tested by:
- (i) Visual examination to determine whether it shows any sign of damage; and
- (ii) Spinning freely its wheel set or manually rotating the bearing to determine whether the bearing makes any unusual noise.
- (2) The roller bearing shall be disassembled from the axle and inspected internally if—
- (i) It shows any external sign of damage;
- (ii) It makes any unusual noise when its wheel set is spun freely or the bearing is manually rotated;
- (iii) Its truck was involved in a derailment at a speed of more than 10 miles per hour; or
- (iv) Its truck was dragged on the ground for more than 200 feet.
- (3) Each defective roller bearing shall be repaired or replaced before the car is placed back in service.

[44 FR 77340, Dec. 31, 1979, as amended at 45 FR 26711, Apr. 21, 1980]

§ 215.117 Defective roller bearing adapter.

A railroad may not place or continue in service a car, if the car has a roller bearing adapter that is—


- (a) Cracked or broken;
- (b) Not in its design position; or
- (c) Worn on the crown of the adapter to the extent that the frame bears on

the relief portion of the adapter, as shown in the figure below (see figure 1).

§ 215.119 Defective freight car truck.

A railroad may not place or continue in service a car, if the car has—

- (a) A side frame or bolster that-
- (1) Is broken; or
- (2) Has a crack of ¼ of an inch or more in the transverse direction on a tension member;
- (b) A truck equipped with a snubbing device that is ineffective, as evidenced by—
- (1) A snubbing friction element that is worn beyond a wear indicator;
- (2) A snubber wear plate that is loose, missing (except by design), or worn through:
- (3) A broken or missing snubber activating spring; or



- FIGURE 1
- (4) Snubber unit that is broken, or in the case of hydraulic units, is broken or leaking clearly formed droplets of oil or other fluid.
- (c) A side bearing in any of the following conditions:
- (1) Part of the side bearing assembly is missing or broken;
- (2) The bearings at one end of the car, on both sides, are in contact with the body bolster (except by design);
- (3) The bearings at one end of the car have a total clearance from the body bolster of more than ¾ of an inch; or
- (4) At diagonally opposite sides of the car, the bearings have a total clearance from the body bolsters of more than ¾ of an inch;
 - (d) Truck springs—
- (1) That do not maintain travel or load:
- (2) That are compressed solid; or
- (3) More than one outer spring of which is broken, or missing, in any spring cluster;
- (e) Interference between the truck bolster and the center plate that prevents proper truck rotations; or