zone are separated both vertically and horizontally as widely as practicable.

(b) Machinery spaces. Lighting for enginerooms, boilerrooms, and auxiliary machinery spaces must be supplied from two or more feeders. One of these feeders must be a ship's service feeder

NOTE: Special requirements for emergency lighting, feeders, and branch circuits are in subpart 112.43 of this chapter.

[CGD 74-125A, 47 FR 15236, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28282, June 4, 1996; 61 FR 33045, June 26, 1996]

§111.75-5 Lighting branch circuits.

- (a) Loads. A lighting distribution panel must not supply branch circuits rated at over 30 amperes.
- (b) Connected load. The connected load on a lighting branch circuit must not be more than 80 percent of the rating of the overcurrent protective device, computed on the basis of the fixture ratings and in accordance with IEEE Std 45, section 21.6.
- (c) Lighting fixtures on lighting circuits. Each lighting fixture must be on a lighting branch circuit.
- (d) Overcurrent protection. Each lighting branch circuit must be protected by an overcurrent device rated at 20 amperes or less, except as allowed under paragraph (e) of this section.
- (e) 25 or 30 ampere lighting branch circuits. Lighting branch circuits rated at 25 and 30 amperes supplying only fixed nonswitched lighting fixtures for cargo hold or deck lighting having only lampholders of the mogul type, or other lampholding devices required for lamps of more than 300 watts, may be supplied by a 30 ampere branch circuit wired with at least No. 10 AWG (5.3 mm²) conductors if each fixture wire used in wiring each lighting fixture is No. 12 AWG (3.3 mm²) or larger.

[CGD 74–125A, 47 FR 15236, Apr. 8, 1982, as amended by CGD 94–108, 61 FR 28282, June 4, 1996; 62 FR 23909, May 1, 1997]

§111.75-15 Lighting requirements.

(a) Lights in passageways, public spaces, and berthing compartments. The supply to lights in each passageway, public space, or berthing compartment accommodating more than 25 persons must be divided between two or more

branch circuits, one of which may be an emergency branch circuit.

- (b) Lights in machinery spaces. Alternate groups of lights in an engineroom, boilerroom, or auxiliary machinery space must be arranged so that the failure of one branch circuit does not leave an area without light.
- (c) Illumination of passenger and crew spaces. (1) Each space used by passengers or crew must be fitted with lighting that provides for a safe habitable and working environment under normal conditions.
- (2) Sufficient illumination must be provided by the emergency lighting source under emergency conditions to effect damage control procedures and to provide for safe egress from each space.
- (d) Berth lights. Each crew berth must have a fixed berth light that is not wired with a flexible cord. The berth light must have minimum horizontal projection so that the light may not be covered with bedding.
- (e) Exit lights. Each exit light required on passenger vessels under §112.15–1 of this subchapter must have the word "Exit" in red block letters at least 2 inches (50 mm) high.
- (f) *Pilot ladders.* There must be a means for lighting each station from which a pilot may be deployed.

[CGD 74-125A, 47 FR 15236, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28282, June 4, 1996]

§111.75–16 Lighting of survival craft and rescue boats.

- (a) During preparation, launching, and recovery, each survival craft and rescue boat, its launching appliance, and the area of water into which it is to be launched or recovered must be adequately illuminated by lighting supplied from the emergency power source.
- (b) The arrangement of circuits must be such that the lighting for adjacent launching stations for survival craft or rescue boats is supplied by different branch circuits.

[CGD 94-108, 61 FR 28282, June 4, 1996]

§111.75-17 Navigation lights.

Each navigation light system must meet the following:

§ 111.75-18

- (a) Feeders. On vessels required to have a final emergency power source by §112.05-5(a) of this chapter, each navigation light panel must be supplied by a feeder from the emergency switchboard (see §112.43-13). The feeder must be protected by overcurrent devices rated or set at a value of at least twice that of the navigation light panel main fuses.
- (b) Navigation light indicator panel. Each self-propelled vessel must have a navigation light indicator panel in the navigating bridge to control side, masthead, and stern lights. The panel must visually and audibly signal the failure of each of these navigation lights. Each light source must be connected to a separate fused branch circuit. The panel must have a fused feeder disconnect switch, and the fuses must have at least twice the rating of the largest branch circuit fuse and must be greater than the maximum panel load.
- (c) *Dual light sources*. Each self-propelled vessel must have duplicate light sources for the side, masthead, and stern lights.
- (d) Navigation lights. Each navigation light must meet the following:
- (1) Meet the technical details of the applicable navigation rules.
- (2) Be certified by an independent laboratory to the requirements of UL 1104 or an equivalent standard under §110.20-1 of this chapter. Portable battery powered lights need meet only the requirements of the standard applicable to those lights.
- (3) Be labeled with a label stating the following:
- (i) "MEETS _____." (Insert the identification name or number of the standard under paragraph (d)(2) of this section to which the light was typetested.)
- (ii) "TESTED BY ____." (Insert the name or registered certification mark of the independent laboratory that tested the fixture to the standard under paragraph (d)(2) of this section).
 - (iii) Manufacturer's name.
 - (iv) Model number.
- (v) Visibility of the light in nautical miles.
- (vi) Date on which the fixture was type-tested.

- (vii) Identification of bulb used in the compliance test.
- (4) If it is a flashing light, have its intensity determined by the formula:

Ie=G/(0.2+t2-t1)

Where

Ie=Luminous Intensity.

G=Integral of Idt evaluated between the limits of t1 and t2.

t1=Time in seconds of the beginning of the flash.

t2=Time in seconds of the end of the flash. I=Instantaneous intensity during the flash.

NOTE: The limits, t1 and t2, are to be chosen so as to maximize Ie.

- (e) *Installation of navigation lights.* Each navigation light must:
- (1) Be installed so that its location and its angle of visibility meet the applicable navigation rules;
- (2) Except as permitted by the applicable navigation rules, be arranged so that light from a navigation light is not obstructed by any part of; the vessel's structure or rigging;
- (3) Be wired by a short length of heavy-duty, flexible cable to a water-tight receptacle outlet next to the light or, for permanently mounted fixtures, by direct run of fixed cable; and
- (4) If it is a double-lens, two-lamp type, have each lamp connected to its branch circuit conductors either by an individual flexible cable and watertight receptacle plug or, for permanently mounted fixtures, by an individual direct run of fixed cable.

[CGD 74-125A, 47 FR 15236, Apr. 8, 1982, as amended by CGD 94-108, 61 FR 28282, June 4, 1996; 61 FR 33045, June 26, 1996; 62 FR 23909, May 1, 1997]

§111.75-18 Signaling lights.

Each self-propelled vessel over 150 gross tons when engaged on an international voyage must have on board an efficient daylight signaling lamp that may not be solely dependent upon the vessel's main source of electrical power and that meets the following:

- (a) The axial luminous intensity of the beam must be at least 60,000 candelas.
- (b) The luminous intensity of the beam in every direction within an angle of 0.7 degrees from the axial must