
OPEN WATER SITE MANAGEMENT AND CONTROLS

Susan E. Bailey

US Army ERDC, Vicksburg, MS

Susan.E.Bailey@usace.army.mil







Risk Management

Risk Assessment

Risk Management

**R
I
S
K**



Implemented controls should be commensurate with potential risk...



Open Water Placement Risk Management Considerations

- **Material Suitability**
- **Site Characterization**
- **Site Designation/ Selection**
- **Operational Considerations**
- **Design Evaluations**
- **Control Measures/ Management Actions**
- **Site Management Plan**
- **Monitoring**



Material Suitability

- **Is proposed dredged material suitable for open water placement at the site without special management or controls?**

- **Physical impacts**

- MPRSA sites via site designation
- CWA sites project specific

- **Contaminant impacts**

- MPRSA via OTM procedures
- CWA via ITM procedures




Site Characterization

- **Bathymetry**
- **Water depth/ stratification**
- **Current/ wave conditions**
- **On-site biological resources**
- **Proximity to sensitive resources**



Site Designation/ Selection

- **Ocean Site Designation (MPRSA)**
 - Formal Designation Process
 - EPA Designated General Use (Section 102)
 - USACE Designated Specific Projects (Section 103)
 - Final and Interim Designations
- **Site Selection in US Waters (CWA)**



Operational Considerations

- **Equipment and placement techniques**
- **Time, rate, location, and methods of placement**
- **Quantity and frequency of materials placed**
- **Navigation and positioning**
- **Site controls, e.g. Buoys**
- **Coordinating site use among permit holders**
- **Monitoring**




Tools to Evaluate Effectiveness


- **Water Column Dispersion**
 - STFATE or CDFATE or others
- **Placement technique, location, and rate**
 - Mound Development ~ MDFATE / MPFATE
- **Long-Term Stability and Site Capacity**
 - Consolidation ~ PSDDF
 - Erosion/ Consolidation ~ LTFATE
- **Far Field Transport ~ TABS, ICM, SSFATE**



STFATE




Site 69b, TSS



STFATE Evaluation of Alternatives 3000 CY Barge – Single Dump

Peak Lead Concentrations




● Max Conc on Grid * Max Conc Outside M.Z. — M.Z. Standard



STFATE Evaluation of Alternatives 1500 CY Barge – Single Dump

Peak Lead Concentrations




—●— Max Conc on Grid —*— Max Conc Outside M.Z. — M.Z. Standard



STFATE Evaluation of Alternatives 3000 CY Barge – Spreading

Peak Lead Concentrations



● Max Conc on Grid

★ Max Conc Outside M.Z.

— M.Z. Standard




Open Water Control Measures

- **Water Column Management**

- Submerged discharge
- Geocontainers
- Silt Curtains
- Treatment (polymer addition)
- Reduce discharge rate
- Promote mixing (dump while under tow)

- **Benthic Management**


- Treatment (not typically done)
- Capping with cleaner dredged material or armor
- Lateral confinement or CAD
- Geocontainers



Operational Modifications


- Select different equipment type
- Select different equipment size
- Control placement operation

- Location
- Rate
- Method



Submerged Discharge

- Can reduce water column dispersion
- Can improve accuracy of placement
- Pipeline configurations
- Diffuser design available
- Tremie technolog



Barge with Tremie



Submerged Diffuser





Silt Curtains


- **Purpose**
 - To control SS/turbidity in the water column (mainly at dredging site)
- **Advantages**
 - Can be used to protect sensitive environments
 - Can allow particles to settle out of the upper water column
 - Commercially available
- **Limitations**
 - Strong currents
 - (> 1 knot/1.5 fps)
 - High winds
 - Debris/Ice
 - Excessive wave heights
 - Fluctuating water levels
 - Must allow traffic in/out
 - Bubble curtains
- <http://el.erdc.usace.army.mil/elpubs/pdf/doere21.pdf>



Silt Curtains



Pneumatic Barrier



Geo-containers

- **Geotextiles used for solids containment**
- **Can reduce water column dispersion**
- **Can reduce capping requirements**
- **Engineering design approaches available**
- **Operational aspects need refinement**





Site Management Plans


- Roles and responsibilities
- Management objectives
- Specifics on operations and management
- Inspection and enforcement
- Monitoring requirements



LA-3 Ocean Dredge Material Disposal Site

Estimated barge location at initial dump point:
offset from tug by 250 feet
at 25 degrees azimuth

Note: The coordinates for trips #667, and #1116 are outside of the map extent.



● LA-3 center coordinates:
33°31'42" N 117°54'48" W

● Mis-identified dump target:
33°31'25" N 117°54'29" W

Trips 1-975

Trips 976-1238

● <1000 feet

● <1000 feet

● >1000 feet

● >1000 feet


100 0 200 400 600 800 1000 Feet

Open Water Site Monitoring

- **Need for Monitoring**
 - Evaluate effectiveness of management
 - Evaluate environmental impacts
 - Recommend modifications
- **Monitoring Plan**
 - Clear objectives
 - Testable hypotheses
 - Methods and equipment
- **Management Actions**
- **Silent Inspector**
 - Location
 - Volume



Open Water Monitoring Tools



Summary

- **Site selection / characterization**
- **Material suitability**
- **Planning the disposal operation**
 - Models available
- **Site controls**
- **Site management plan**
- **Monitoring**



Questions??

