

Appendix J

TEM Data for Test #3 Solution Samples

Figures

| | | |
|--------------|---|-----|
| Figure J-1. | Electron micrograph magnified 2000 times for one Test #3, Day-4 filtered sample location. (T3D4F1)..... | J-4 |
| Figure J-2. | TEM energy-dispersive x-ray spectrum for the Day-4 filtered test sample as shown in Figure J-1. (T3D4FEDS)..... | J-4 |
| Figure J-3. | TEM image for Test #3, Day-4 filtered sample solution (T3D4F2) | J-5 |
| Figure J-4. | Electron micrograph magnified 2000 times for one Test #3, Day-4 unfiltered sample location. (T3D4UF2) | J-5 |
| Figure J-5. | TEM energy-dispersive x-ray spectrum for the Day-4 unfiltered test sample as shown in Figure J-4. (T3D4UFEDS)..... | J-6 |
| Figure J-6. | TEM image for Test #3, Day-4 unfiltered sample solution (T3D4UF) | J-6 |
| Figure J-7. | Electron micrograph magnified 4000 times for one Test #3, Day-15 unfiltered sample location. (T3D15U-4k-01)..... | J-7 |
| Figure J-8. | TEM energy-dispersive x-ray spectrum for Test #3, Day-15 unfiltered test sample as shown in Figure J-7. (T3D15UFEDS) | J-7 |
| Figure J-9. | TEM image magnified 2000 times for a Test #3, Day-15 unfiltered sample solution (T3D15U-SAD20cm-01) | J-8 |
| Figure J-10. | Electron micrograph magnified 4000 times for one Test #3, Day-30 unfiltered sample location. (T3D30U-4k-01)..... | J-8 |
| Figure J-11. | TEM energy-dispersive x-ray spectrum for Test #3, Day-30 unfiltered test sample as shown in Figure J-10. (T3D30UFEDS) | J-9 |
| Figure J-12. | TEM image magnified 2000 times for a Test #3, Day-30 unfiltered sample solution (T3D30U-SAD) | J-9 |

This page intentionally left blank.

This appendix presents TEM images, EDS, and diffraction patterns for Test #3, Day-4, Day-15, and Day-30 filtered and unfiltered solution samples. The filtered solution samples were passed through a 0.7- μm fiberglass filter at 60°C. The unfiltered solution samples were extracted from the tank directly. Based on the results, no significant diffraction pattern was observed because of the amorphous nature of the samples. Available logbook entries for this laboratory session are included in this appendix as transcribed notes.

This page intentionally left blank.

Transcribed Laboratory Log

Laboratory session from May 6, 2005.

TEM Test #3, Day-4 solution samples
Test #3, Day-15 filtered and unfiltered solution
Test #3, Day 30 unfiltered solution

TEM Filtered Day-4 Solution Samples

| | | | |
|---------------|--------|---------------------------|------------|
| Image: T3D4F1 | 2000 × | | Figure J-1 |
| EDS: T3D4FEDS | | Spectrum for image T3D4F1 | Figure J-2 |
| Image: T3D4F2 | 2000 × | | Figure J-3 |

TEM Unfiltered Day-4 Solution Samples

| | | | |
|----------------|--------|---------------------------|------------|
| Image: T3D4UF2 | 2000 × | | Figure J-4 |
| EDS: T3D4UFEDS | | Spectrum on image T3D4UF2 | Figure J-5 |
| Image: T3D4UF | 2000 × | | Figure J-6 |

TEM Unfiltered Day-15 Solution Samples

| | | | |
|--------------------------|--------|--------------------------------|------------|
| Image: T3D15U-4k-01 | 4000 × | | Figure J-7 |
| EDS: T3D15UFEDS | | Spectrum on image T3D15U-4k-01 | Figure J-8 |
| Image: T3D15U-SAD20cm-01 | 2000 × | | Figure J-9 |

TEM Unfiltered Day-30 Solution Samples

| | | | |
|---------------------|--------|--------------------------------|-------------|
| Image: T3D30U-4k-01 | 4000 × | | Figure J-10 |
| EDS: T3D30UFEDS | | Spectrum on image T3D30U-4k-01 | Figure J-11 |
| Image: T3D30U-SAD_ | 2000 × | | Figure J-12 |




Figure J-1. Electron micrograph magnified 2000 times for one Test #3, Day-4 filtered sample location. (T3D4F1)




Figure J-2. TEM energy-dispersive x-ray spectrum for the Day-4 filtered test sample as shown in Figure J-1. (T3D4FEDS)




Figure J-3. TEM image for Test #3, Day-4 filtered sample solution (T3D4F2)




Figure J-4. Electron micrograph magnified 2000 times for one Test #3, Day-4 unfiltered sample location. (T3D4UF2)




Figure J-5. TEM energy-dispersive x-ray spectrum for the Day-4 unfiltered test sample as shown in Figure J-4. (T3D4UFEDS)




Figure J-6. TEM image for Test #3, Day-4 unfiltered sample solution (T3D4UF)




Figure J-7. Electron micrograph magnified 4000 times for one Test #3, Day-15 unfiltered sample location. (T3D15U-4k-01)




Figure J-8. TEM energy-dispersive x-ray spectrum for Test #3, Day-15 unfiltered test sample as shown in Figure J-7. (T3D15UFEDS)




Figure J-9. TEM image magnified 2000 times for a Test #3, Day-15 unfiltered sample solution (T3D15U-SAD20cm-01)




Figure J-10. Electron micrograph magnified 4000 times for one Test #3, Day-30 unfiltered sample location. (T3D30U-4k-01)




Figure J-11. TEM energy-dispersive x-ray spectrum for Test #3, Day-30 unfiltered test sample as shown in Figure J-10. (T3D30UFEDS)



Figure J-12. TEM image magnified 2000 times for a Test #3, Day-30 unfiltered sample solution. (T3D30U-SAD)

This page intentionally left blank.

Appendix K

UV Absorbance Spectrum—Day-30 Solution Samples

Figures

Figure K-1. UV absorbance spectrum for Test #3, Day-30 solution samples. K-3

Tables

Table K-1. Test #3, Day-30 Solution Sample Laboratory Settings..... K-4

This page intentionally left blank.

This appendix presents the ultraviolet (UV) absorbance result of the Test #3, Day-30 solution sample. The purpose of this analysis was to find any distinguishing absorbance peaks to identify the organics present in the solution. The solution sample at 60°C was collected through a 0.7- μm fiberglass filter to remove particulate impurities, followed by being scanned over the wavelength ranging from 200 to 800 nm by a UV-visible spectrophotometer. The spectrum of deionized water was used as background subtraction. From the result, the test solution did not exhibit any distinguished absorbance peaks. No logbook entries are available for this laboratory session, so, no transcribed notes are provided in this appendix.

This page intentionally left blank.




Figure K-1. UV absorbance spectrum for Test #3, Day-30 solution samples.

Table K-1. Test #3, Day-30 Solution Sample Laboratory Settings

| Test #3, Day-30 Samples | |
|--------------------------------|---|
| Collection Time: | 5/5/2005 11:33:48 AM |
| Operator Name: | |
| Scan Software Version: | 3.00(182) |
| Parameter List : | |
| Instrument: | Cary 50 |
| Instrument Version: | 3.00 |
| Start (nm): | 800.0 |
| Stop (nm): | 200.0 |
| X Mode: | Nanometers |
| Y Mode: | Abs |
| UV-Vis Scan Rate (nm/min): | 600.00 |
| UV-Vis Data Interval (nm): | 1.00 |
| UV-Vis Ave. Time (s): | 0.1000 |
| Beam Mode: | Dual beam |
| Baseline Correction: | On |
| Baseline Type: | Baseline correction |
| Baseline File Name: | |
| Baseline Std Ref File Name: | |
| Cycle Mode: | Off |
| Comments: | |
| Method Log: | |
| Method Name: | Default |
| Date/Time Stamp: | 5/5/2005 11:28:54 AM |
| Method Modifications: | |
| Cell Changer 6 × 6 Changed: | 5/5/2005 11:28:58 AM / Old:1 / New:0 |
| UVVIS SAT Changed: | 5/5/2005 11:29:22 AM / Old:0.0125 / New:0.1000 |
| NIR SAT Changed: | 5/5/2005 11:29:22 AM / Old:0.0125 / New:0.1000 |
| Common SAT Changed: | 5/5/2005 11:29:22 AM / Old:0.0125 / New:0.1000 |
| Baseline Correction Changed: | 5/5/2005 11:29:22 AM / Old:0 / New:1 |
| Temp Controller Changed: | 5/5/2005 11:29:26 AM / Old:0 / New:2 |

| | |
|--------------------------|--|
| Sipper Type Changed: | 5/5/2005 11:30:11 AM / Old:Internal RSA / New:External sipper |
| End Method Modifications | |
| <Current Wavelength> | 200.1 |

This page intentionally left blank.

Appendix L

ICET Test #3: Pre-Test, Test, and Post-Test Project Instructions

This page intentionally left blank.

The ICET series is conducted under the guidance of PIs, which identify the steps to follow for certain activities. These PIs are revised or rewritten as needed for each test. For Test #3, a new PI was written to address test operations. The PIs that address pre-test and post-test operations were revised for Test #3. These three PIs are included in this appendix to describe more completely the test apparatus and chemical solution preparations, the test startup and daily sampling, and the steps followed after test shutdown.

This page intentionally left blank.

1.0 INTRODUCTION

1.1 PURPOSE

The purpose of this instruction is to ensure that all data acquisition, test samples, testing supplies, chemicals, and related materials are ready and accounted for prior to testing. In addition, this instruction provides instructions on preparing the chemical test apparatus for testing.

1.2 SCOPE

The pre-test operations preparation will ensure that successful initiation of the testing activity is achieved.

1.3 REFERENCES

- Test Plan: Characterization of Chemical and Corrosion Effects Potentially Occurring Inside a PWR Containment Following a LOCA, Revision 12.c, March 30, 2005
- Test 2 Chemical Additive Analysis – ICET-CALC-011
- Laboratory Safety Guidelines
- ASTM A 380 – 99, Standard Practice for Cleaning, Descaling, and Passivation of Stainless Steel Parts, Equipment, and Systems
- Material Safety Data Sheets (MSDS) for all chemicals involved

2.0 PREREQUISITES

The data acquisition setup and inspection; instrument calibration; and the coupon receipt, preparation, inspection, and storage tasks must be completed in full prior to the completion of this activity. Fiberglass and calcium silicate (cal-sil) samples must be weighed and their planned locations in the tank identified. That data must be recorded.

2.1 Training Requirements

The following personnel training is required for this task:

- 1) LabVIEW and computer data acquisition training
- 2) Chemical handling training, specifically for ethyl alcohol, ammonium hydroxide, and lithium hydroxide.
- 3) Safe lift execution training

2.2 Equipment Requirements

The following equipment is required to perform this activity: computer with installed LabVIEW software, data acquisition system, and fully assembled and calibrated ICET test apparatus.

Safety equipment must be available: goggles, gloves, lab coats, eye wash station.

3.0 DOCUMENTATION REQUIRED

MSDSs must be available for all chemicals used.

A lab notebook must be maintained throughout the pre-test operations instruction. Contained within the lab notebook will be the date, times, description of activities, and quantities of chemicals added, number of cleanings, and physical observations of the tank cleaning and preparation procedures.

4.0 HAZARDS

The hazards associated with this activity include potential injuries associated with chemical handling.

5.0 INSTRUCTIONS

1. Ensure that all testing materials and supplies are ready and on-site. See checklist at the end of this document. Verify that eye wash station is operational. Note: The following solutions are not used in this instruction, but are to be prepared in advance of entering ICET-PI-014, "Test Operations, Test #3 (cal-sil and fiberglass with TSP)." After preparation, clearly label the containers with the solutions and place in an area restricted for ICET Project test use.
2. Prepare 21.2 g of concrete dust and 63.7 g of latent debris.
3. Prepare LiOH solution: dissolve 0.663 g of lithium hydroxide (LiOH) into about 100 mL water in a 250-mL sample container.
4. Prepare TSP Solution Batch 1.
 - a. Heat about 1.5 gallons of demineralized water, add 300 g of boric acid (H_3BO_3), and stir until the boric acid is dissolved. Pour the solution into a 5-gallon plastic container. Dissolve the boric acid in multiple batches if necessary.
 - b. Add additional demineralized water to the 5-gallon plastic container until it contains about 4 gallons.
 - c. Dissolve 1893 g of TSP ($Na_3PO_4 \cdot 12H_2O$) into the water in the container.
 - d. Dilute with additional demineralized water until the volume is 5 gallons.
 - e. Label container as "TSP Solution Batch 1."
5. Prepare TSP Solution Batch 2.
 - a. Heat about 1.5 gallons of demineralized water, add 300 g of boric acid (H_3BO_3), and stir until the boric acid is dissolved. Pour the solution into a 5-gallon plastic container. Dissolve the boric acid in multiple batches if necessary.

- b. Add additional demineralized water to the 5-gallon plastic container until it contains about 4 gallons.
 - c. Dissolve 1893 g of TSP ($\text{Na}_3\text{PO}_4 \cdot 12\text{H}_2\text{O}$) into the water in the container.
 - d. Add 211 mL of 12.29 N hydrochloric acid (HCl) to the water in the container.
 - e. Dilute with additional demineralized water until the volume is 5 gallons.
 - f. Label container as "TSP Solution Batch 2."
6. Prepare laboratory control sample (LCS). See ICET-PI-005, "Chemical Sampling and Analysis," for details on the laboratory control sample.
 7. Start the data acquisition system. Verify that the data acquisition system is monitoring flow rate, pump speed, temperature, and pH.
 8. Clean the tank and piping.
 - a. Cleaning should commence as soon after a test is completed as possible, to prevent material from hardening in the tank or piping and to maximize the time available for cleaning.
 - b. Cleaning chemicals may consist of weak acids (e.g., acetic acid, citric acid, or dilute mineral acids), weak bases (e.g., ammonium hydroxide), weak organic solvents (e.g., ethanol), or detergents/surfactants (e.g., trisodium phosphate, sodium dodecyl sulfate), as necessary. Cleaning solutions can be heated if necessary. Note that the discharge limit to the sanitary sewer is a maximum temperature of 140 °F and pH between 5.0 and 11.5. Cleaning solutions that are not within this range should be neutralized before discharge.
 - c. During cleaning, the pump should be run and water directed through both recirculation lines (through the spray nozzles and lower headers)
 - d. The sample line should be removed from the piping, physically cleaned, and carefully inspected. If the sample line cannot be adequately cleaned, it should be replaced.
 - e. After each cleaning step, the tank and piping should be thoroughly rinsed with tap water or demineralized water.
 - f. After each cleaning step, a segment of pipe should be removed, and the interior of the pipe visually inspected.
 - g. Cleanliness criteria: When the tank visually appears to be satisfactorily cleaned, the tank and piping should be thoroughly rinsed with demineralized water. The interior surfaces of the tank and piping shall be free of any deposits that can be removed by vigorous scrubbing. Demineralized water drained from the tank should have turbidity less than 0.3 NTU and conductivity less than 50 uS/cm.
 9. Tank is now ready for testing. Proceed immediately to Instruction No. ICET-PI-014, "Test Operations, Test #3 (cal-sil and fiberglass with TSP).

6.0 ATTACHMENTS

No forms are attached to this document.

7.0 Materials Checklist

- _____ lithium hydroxide, 0.663 g
- _____ TSP, 3.785 kg
- _____ 211 mL of 12.29 N HCl
- _____ Boric acid, 600 g
- _____ tap water supply
- _____ demineralized water production system
- _____ chemical handling safety equipment (lab coat, goggles, rubber gloves)
- _____ analytical balance
- _____ top loading balance
- _____ chemical spatula
- _____ chemical scoop
- _____ weigh boats
- _____ two 5-gallon plastic containers
- _____ 250 mL graduated cylinder
- _____ 250-mL HDPE or PP bottle
- _____ 2.5 gallons ethanol
- _____ 2.5 gallons ammonium hydroxide
- _____ turbidimeter and associated equipment
- _____ conductivity meter and associated equipment

1.0 INTRODUCTION

1.1 PURPOSE

The intent of the instruction is to outline the steps that are to be followed during testing.

1.2 SCOPE

This activity forms the core of the entire Chemical Effects Testing project. All activities involved in this project affect and are affected by this activity.

1.3 REFERENCES

- Test Plan: Characterization of Chemical and Corrosion Effects Potentially Occurring Inside a PWR Containment Following a LOCA, Revision 12.c, March 30, 2005
- ASTM Standard G 4-01
- ASTM Standard D 3370-95a
- ASTM Standard G 31-72
- Material Safety Data Sheets (MSDS) for all chemicals involved
- LabVIEW operation manual
- Laboratory Safety Guidelines
- Test 2 Chemical Additive Analysis – ICET-CALC-011
- John Gisclon email to Bhagwat Jain, Cal-sil Information Used in Test #3, March 31, 2005

2.0 PREREQUISITES

All sample coupons must be placed in their corresponding racks. Also, the pre-operation test preparation activity must be completed in full.

2.1 Training Requirements

The following personnel training is required for this task:

- 1) LabVIEW and computer data acquisition training.
- 2) Chemical handling training for all chemicals involved.

2.2 Equipment Requirements

The following equipment is required to perform this activity: computer with installed LabVIEW software, data acquisition system, and fully assembled and calibrated ICET test apparatus.

Safety equipment must be available: goggles, gloves, lab coats, hard hats, steel-toed shoes, eye wash station, hydrogen detector and hydrogen removal system.

3.0 DOCUMENTATION REQUIRED

A lab notebook must be maintained throughout the testing procedure. In addition, a binder will be maintained that includes pertinent test instructions and the completed daily log sheets (see Attachment A). The daily log sheet contains the date, times, physical description, and quantity of fiberglass and water samples obtained each day. In addition, the daily log sheet contains information from the data acquisition system (DAS), the water samples taken, and other test information.

The electronic data that are acquired are backed up daily and stored in a separate location each testing day. Refer to ICET-PI-001, Data Acquisition Setup and Inspection.

4.0 HAZARDS

The hazards associated with this activity include tipping of the chemical tank assembly, ingestion and/or respiration of any chemicals involved, and scalding and/or burning hazards involved in daily tank venting, and possible hydrogen gas generation from corrosion reactions. Appropriate measures to control hydrogen gas must be in place before operations commence.

Lifting hazards associated with the tank lid and coupon racks are also associated with this activity.

5.0 INSTRUCTIONS

1. Because of the time required for heating the tank contents and dissolving chemicals, this sequence should be started at least 48 hours before the scheduled time $t = 0$. Pre-Test Operations preparation should be complete before proceeding with this sequence.
2. Ensure that all testing materials and supplies are ready and on-site (see checklist at end of this instruction).
3. Add 240 gallons of RO water to the tank by pumping water from the RO skid through the totalizing flow meter. Record flow to the nearest 0.5 gallon.
4. Verify valves are positioned as follows:

| Valve | Description | Position |
|-------|------------------------------|----------|
| V-1 | tank drain | closed |
| V-2 | pump isolation | open |
| V-3 | instrument loop supply | open |
| V-4 | instrument loop discharge | open |
| V-5 | instrument loop bypass | closed |
| V-6 | in-line filter isolation | open |
| V-7 | tank spray supply | closed |
| V-8 | recirculation supply | open |
| V-9 | sample line | closed |
| V-10 | loop drain | closed |
| V-11 | recirculation line injection | closed |

5. Start pump and adjust to flow rate of approximately 25 gpm.
6. Start computer, start LabVIEW, verify that flow rate, pump speed, temperature, and pH are being recorded properly.
7. Turn on heater and allow water in tank to heat to $60\text{ }^{\circ}\text{C} \pm 2\text{ }^{\circ}\text{C}$. (This may take up to 20 hours.)
8. Add the pre-mixed LiOH solution.
9. Add 14.54 kg of boric acid (H_3BO_3), weighing in approx. 2 kg increments, recording the weight of each increment to the nearest 10 g.
10. Allow the water to circulate until the solution is visibly clear, indicating that the boric acid is completely dissolved.
11. Allow water in tank to heat to $65\text{ }^{\circ}\text{C} \pm 2\text{ }^{\circ}\text{C}$.
12. Take grab water sample for analysis for the parameters identified in steps a – h below. Also record physical appearance of the sample (clarity, presence of gelatinous material, etc). All Day 1 and subsequent samples will be analyzed by Assaigai Analytical Laboratory. In addition, periodic test samples and laboratory control samples (LCSs) will also be analyzed by the UNM laboratory.
 - a. pH
 - b. temperature
 - c. turbidity
 - d. viscosity
 - e. total suspended solids (TSS)
 - f. dissolved oxygen (DO)
 - g. chloride
 - h. metals (Al, B, Ca, Cu, Fe, Pb, Li, Mg, Ni, K, Si, Na, and Zn), total and dissolved
13. Add 21.2 g of concrete dust and 63.7 g of latent debris samples (prepared earlier), wait 10 minutes, take 100 mL water sample for particulate size distribution, density, and TSS.
14. Stop pump.
15. Add the pre-determined amount of cal-sil dust. This will be approximately 43.5 lb.

16. Place coupon racks, fiberglass holders, and cal-sil holders into tank. This is done in accordance with previously determined quantities, size distributions, and locations. (Details of the cal-sil preparation and size distributions are given in the referenced email.)
17. Verify locations of coupon racks, fiberglass holders, and cal-sil holders.
18. Verify the tank temperature is 62 °C. (Because the tank lid will be off, the test will be started with the water temperature at its upper limit.)
19. Start pump and adjust pump speed to 25 gpm.
20. Open valve V-7 (tank spray supply) to direct water to nozzles and adjust valves V-7 (tank spray supply) and V-8 (recirculation supply) until nozzle flowmeter is reading 3.5 gpm. Verify total flow is still 25 gpm and adjust variable frequency drive (VFD) if necessary.
21. Record date and time at which nozzle flow started. This is time $t = 0$ for the test.
22. The spray phase will begin with the tank lid off. The objective is to be able to carefully monitor possible nozzle blockage and take immediate action to prevent it. At the first sign that a nozzle may be starting to plug, the spray flow rate should be increased rapidly to 5-10 gpm for approximately 5 s. (As long as the nozzle spray pattern is not affected however, the spray flow should remain at 3.5 gpm.) If a nozzle should block in spite of the increased flow rate, a stainless steel wire should be used to clear the nozzle exit.
23. If the spray through the nozzles is not affected by the cal-sil and shows no signs of blocking for a period of 15 minutes, the tank lid should be put in place. Flow through the nozzles should continue to be monitored every 5 minutes by looking through the tank view windows. In addition, every 15 minutes, the spray flow should be bumped to 5-10 gpm for approximately 5 s.
24. At 30 minutes, open valve V-11 (recirculation line injection) and start chemical metering pump from TSP Solution Batch 1 at a rate of 0.0476 gpm (180 mL/min). The objective here and in step #25 is to add a total of 10 gallons of TSP solution in 3.5 hours.
25. After 2 hours, switch the chemical metering pump to TSP Solution Batch 2.
26. Take a measurement of hydrogen concentration. At 2-hour increments, repeat the hydrogen concentration measurement. If the concentration reaches 10% of the flammability limit, purge the tank atmosphere. This needs to be repeated until the hydrogen concentration has been determined to be below 10% of the flammability limit, and then the frequency of hydrogen concentration measurements is to be re-evaluated.
27. At $t = 4$ hours, stop the chemical metering pump and close valves V-7 and V-11.
28. Immediately after closing valves V-7 and V-11 (at $t = 4$ hours), take water grab sample for analysis for the parameters listed below. Record the time of sample collection.
 - a. pH
 - b. temperature
 - c. turbidity

-
- d. viscosity
 - e. chloride
 - f. total suspended solids (TSS)
 - g. dissolved oxygen (DO)
 - h. metals (Al, B, Ca, Cu, Fe, Pb, Li, Mg, Ni, K, Si, Na, and Zn), total and dissolved
29. At $t = 24$ hours, and daily thereafter, take water grab sample for analysis for the parameters listed below. (The LANL PI will propose a different sampling frequency to the project sponsors if test data support it.) Record the time of sample collection.
- a. pH
 - b. turbidity
 - c. viscosity
 - d. temperature
 - e. total suspended solids (TSS)
 - f. metals (Al, B, Ca, Cu, Fe, Pb, Li, Mg, Ni, K, Si, Na, and Zn), total and dissolved. An exception is that B, Li, K, Pb, and chloride analyses will be performed only at $t = \text{days } 15 \text{ and } 30$. Also, dissolved oxygen will be measured at day 30.
30. During each daily water sample collection, look inside tank (through windows) and record observations. If the tank water level indicates that the water volume is 245 gallons or less, add RO water to bring the volume up to 250 gallons and record the amount added.
31. At $t = 24$ hours, weekly thereafter, and at the end of the test, collect 100 mL water sample for particulate size distribution and density analysis, to be performed at AALI. The particulate size ranges to be used will be as close as possible to those called out in the test plan: (in microns), 1-10, 11-25, 26-50, 51-75, 76-100, and > 100 microns.
32. At $t = 24$ hours, weekly thereafter, and at the end of the test, collect water samples for strain rate viscosity measurements (see PI-010 for sample details.)
33. At $3 \text{ days} \leq t \leq 5 \text{ days}$, $14 \text{ days} \leq t \leq 16 \text{ days}$ and at the end of the test, collect a sacrificial fiberglass sample to be inspected and examined with SEM.
34. At 24 hours, at $14 \text{ days} \leq t \leq 16 \text{ days}$ and at the end of the test, run 1L of water through a nucleopore filter. The filter will be taken for SEM analysis as specified in ICET-PI-007. (Note that depending on the solution, some filter material will not work well for this operation. If possible, use a nucleopore filter for SEM analysis, and then collect a second sample on nitrocellulose filter for later digestion and ICP analysis.)
35. Shut down pump
36. Indicate end of test on the data acquisition system and shut down the data acquisition software.
37. Proceed directly to PI-008 Post-Test Operations.

6.0 ATTACHMENTS

Attachment A. Daily Log Sheet.

7.0 MATERIAL CHECKLIST

- _____ boric acid, 14.54 kg
- _____ pre-mixed lithium hydroxide solution
- _____ concrete dust, 21.2 g
- _____ latent debris, 63.7 g
- _____ Nucleopore filter
- _____ TSP, 3786 g evenly mixed in two 5-gallon containers
- _____ chemical handling safety equipment (lab coat, goggles, rubber gloves)
- _____ top-loading balance
- _____ weigh pan for 2 kg aliquots of boric acid
- _____ stainless steel filter paper holder
- _____ 500 mL graduated cylinder (for TSS)
- _____ totalizing flow meter
- _____ sample containers (see Chemical Sampling Instruction)
- _____ analytical equipment (see Chemical Sampling Instruction)
- _____ pre-assembled coupon racks
- _____ pre-assembled fiberglass baskets, total of 2.2 lb of fiberglass
- _____ pre-assembled cal-sil baskets, total of 26.7 lb of cal-sil
- _____ pre-measured cal-sil dust, 43.5 lb
- _____ coupon handling safety equipment (hard hat, leather gloves, boots)
- _____ computer disks for backup of Labview data
- _____ Masterflex peristaltic pump and tubing
- _____ demineralized water production system

Attachment A. Daily Log Sheet

**Daily Log Sheet
Integrated Chemical Effects Test (Test # 2)**

Date: _____ Time of sample collection: _____
Sample taking and data reduction by _____ and _____

Sample bottle identification:

Assagai (total): _____
Assagai (filtered): _____
UNM (total): _____
UNM (filtered): _____

Control system readings:

Temperature: _____ Flow: _____ pH: _____

Analyses:

Volume filtered for TSS: _____ pH: _____
Temperature: _____ Dissolved oxygen: _____
Turbidity (at 60 °C): _____ (at 23 °C; and 10 min.) _____
Viscosity, unfiltered (60 °C): _____ (at 23 °C) _____
Viscosity, filtered (60 °C): _____ (at 23 °C) _____
Water Level: _____ Water Added: _____
Hydrogen: _____ Other: _____
Fiberglass or other samples taken: _____
TSS filter #: _____ TSS (mg/L): _____

Comments:

Observations written in lab notebook by _____

Continued on back

1.0 INTRODUCTION

1.1 PURPOSE

The intent of this instruction is to ensure that the experimental samples are removed from the test apparatus, the test apparatus is rinsed and inspected, and the test apparatus is made ready for subsequent pre-test operations.

1.2 SCOPE

This activity marks the end of one chemical effects test run. Experimental sample removals and inspections, test apparatus rinsing, and preparations for cleaning and subsequent tests are addressed here.

1.3 REFERENCES

- Test Plan: Characterization of Chemical and Corrosion Effects Potentially Occurring Inside a PWR Containment Following a LOCA, Revision 12.c, March 30, 2005
- ASTM Standard G 4-01
- ASTM Standard G 31-72
- ICET-PI-002, Coupon Receipt, Preparation, Inspection, and Storage, November 19, 2004
- ICET-PI-014, Rev. 0, Test Operations, Test #3 (cal-sil and fiberglass, with TSP, April 5, 2005
- ICET-PI-005, Rev. 1, Chemical Sampling and Analysis, February 3, 2005
- Laboratory safety guidelines
- ICET Project Safety Plan

2.0 PREREQUISITES

All test operation PI criteria must be completed prior to conducting this task.

2.1 Training Requirements

- Laboratory Safety Guidelines
- ICET Project Safety Plan

2.2 Equipment Requirements

A city tap water supply outlet is required for this activity and chemical handling and lifting safety equipment. A reverse osmosis unit is required for the final flush.

3.0 DOCUMENTATION REQUIRED

Documentation related to test parameters, chemical water analyses, coupon and fiberglass examinations, and daily test operations are outlined elsewhere. In this instruction, the steps required to remove samples from the test apparatus and to make it ready for the next test are outlined. In addition, observations as to the test apparatus' condition are obtained and recorded here.

4.0 HAZARDS

The hazards associated with this activity include ingestion/respiration and/or dermal and eye contact with residual chemicals. Lifting hazards associated with the tank lid and coupon racks are also associated with this activity.

5.0 INSTRUCTIONS

- 1) On the last day of testing, collect water samples and perform analyses as outlined in ICET-PI-014 and ICET-PI-005.
- 2) Remove 10L of water from the test apparatus and store at test temperature, for future analyses
- 3) Shut off the recirculation pump.
- 4) Remove the small fiberglass samples for SEM examination.
- 5) Leave one heater on and continue to monitor tank water temperature.
- 6) Isolate and drain the test apparatus piping.
- 7) Remove the tank lid.
- 8) Before removing coupon racks or insulation samples, examine and take photographs and notes of the inside of the tank, the coupons and racks, and the insulation samples.
- 9) Remove the six non-submerged coupon racks to a staging area for drying and post-test examinations (refer to ICET-PI-002).
- 10) Take additional photographs of the inside of the tank.
- 11) Drain the tank slowly, down to the level that uncovers the submerged rack, but keeping the water level above the heater.
- 12) Remove the submerged coupon rack to the staging area.
- 13) Repeat step # 10.
- 14) Turn off the heater.
- 15) Completely drain the tank, taking precautions so that the sediment on the bottom of the tank is not disturbed any more than necessary.
- 16) Store water that was drained from the test apparatus until it is cleared for disposal or shipment. (This step was just moved from later in the PI – the old step #26.)
- 17) When the tank is drained, repeat step # 10. Note especially the locations and orientations of the remaining samples.
- 18) Remove the remaining insulation samples to the staging area to dry.

- 19) Ensure that all samples removed from the tank are clearly marked as to their location and orientation within the tank.
- 20) After all samples have been removed, repeat step # 10.
- 21) Inspect the interior of the tank, noting any observations.
- 22) Note the presence of any sediment. Carefully remove as much sediment as possible, noting any unique aspects of it, such as location. Place the sediment in plastic containers with lids, marking the location of the sediment in the tank.
- 23) Remove the tank drain screen and remove the insulation sample for future analysis.
- 24) Remove the flow meter from the loop and take pictures of the flow meter interior.
- 25) Remove any deposits within the flow meter and place the deposits in plastic containers with lids. This is to keep the samples hydrated.
- 26) Remove a section of pipe, take pictures of the pipe interior, and remove and store any deposits there.
- 27) Replace the flow meter and piping section.
- 28) Rinse the tank with tap water and drain the water.
- 29) Fill the system with 250 gallons of tap water and circulate water through the spray nozzles and recirculation headers for at least 60 minutes. Repeat with de-mineralized water.
- 30) If any signs of deterioration are observed on the inside of the test apparatus tank, remove selected insulation on the tank. Inspect the stainless steel tank for any abnormalities.

6.0 ATTACHMENTS

No forms are attached to this document.