


# Air Quality Data



A New Conceptual Approach

# Outline

- 
- Goal
  - Present Concept
  - Problems
  - New Concept
  - Advantages
  - Approach
  - Network Design
  - Example Application



# Basic Goal

Produce a complete SPATIAL picture of air quality in a cost effective manner with acceptable uncertainty



# Present Concept

- Air Quality Data (AQD) are truth (no uncertainty)
- **BUT:** Where there are no monitors there is no information



# Problems With the Present Concept

- AQD “truth” is simply what a monitor recorded at a specific place and time. Its relevance and certainty depend on its use and instrument error.
- We use monitored AQD to represent unmonitored areas (i.e., 10 ft. from the monitor) – WE ESTIMATE!
- To use AQD we must create a spatial picture (implicit interpolation) – e.g.:
  - AQD are representative of the entire area of the county in which they are taken
  - AQD provide no information outside the county in which they are taken
- For a complete spatial picture monitors are needed everywhere (including counties that have monitors) -network optimization is meaningless
- Disincentive to monitor



# New Concept

- Air Quality Concept:
  - Actual monitored or estimated (kriged) air quality are the same except for uncertainty
  - Define air quality as a estimated field of actual concentrations and their associated uncertainties
- Estimate Actual Concentration Field:
  - AQD are simply a sample of the “Actual” air quality
  - AQD are used as input to an interpolation model (kriging) to estimate the actual concentration field
  - Use area modeling to establish the best variogram for kriging
- Estimate uncertainty using area modeling



# Advantages to New Concept

- The complete field of air quality is available for policy development, trends analysis, etc.
- The estimated concentration field is robust
  - Changes to an optimized network should not significantly affect the estimates
  - Lack of county monitors does not result in NO data
- Removes monitoring disincentive
- Provides a direct blueprint for developing optimal cost-effective networks




# Approach:


- Constructing actual concentration field:
  - Produce a BENCHMARK concentration field from area modeling (modeling data must adequately characterize important features of the field)
  - Establish the best variogram model for the area using the benchmark data
  - Estimate, through kriging, the actual concentration field using:
    - The variogram model constructed from the benchmark data
    - All available monitored air quality values both within and outside the area




# Ozone Monitoring Network used for Kriging



# 1999 8hr. Ozone Design Value: Kriged Grid with Network Overlay



# 1999 Ozone Design Values: Kriged Contour Map






# Approach (cont.):


## ■ Constructing uncertainty field

- Develop a subset of the benchmark (modeled) data from monitor locations only
- Estimate the actual concentration field by kriging the benchmark data subset
- Compare the full benchmark field with the estimated field from the benchmark subset
- Construct a field of residuals (the uncertainty field)


BENCHMARK Data Set  
4<sup>th</sup> High 8hr. Ozone: UAM-V Model Output  
1996 Emissions Inventory  
30 Days of 1995 Met




# Constructing Data Subset (modeled values at monitor locations) from Benchmark UAM-V Modeling




Benchmark Data Set



Kriged Data Set



Ratio of Kriged  
To Benchmark





# Network Design

- **PREMISE:** An optimum network is one that produces minimum uncertainty for acceptable resource demand.
- **GENERAL APPROACH:**
  - Develop a benchmark (modeled) concentration field
  - Construct various data subsets from the benchmark data (i.e., network designs)
  - Estimate (krig) a concentration field for each network design






# Network Design (cont.)


## ■ GENERAL APPROACH (cont.):

- Compare each estimated field to the benchmark field
- Choice the best design: establish point of diminishing returns
- Example:
  - Existing Network Corr Coeff = .89
  - Add monitor: Albemarle county Corr Coeff = .90
  - Add Albemarle & Harrison county Corr Coeff = .91



Existing Network (Corr Coeff = 0.89)



Add Albemarle (Corr Coeff = 0.90)




Add Harrison  
(Corr Coeff = 0.91)



Ratio of Kriged  
To Benchmark

# Ratio of Kriged to Benchmark:

Black = Present Network; Red = + Albemarle; Blue = + Harrison





# Network Design (cont.)

## ■ Plan for Optimizing Present Network

- Develop appropriate benchmark data set (use existing modeled data if possible)
- Develop the best variogram model for kriging
- Develop optimization criteria
  - Comparison statistics: Correlation Coefficient; Maximum residual; Etc.
  - Resource demand
  - State preference
  - Etc.
- Compare Benchmark with estimated “present network” field : establish baseline stats.
- Optimize Network
  - Create potential new network
    - Examine uncertainty (residual) fields
    - Remove &/or add monitors
  - Compare new network with Baseline
  - Iterate to find optimal network



# Application of New Approach

- Use of Interpolated AQ for Region III 8hr. Ozone Attainment Designations
- PROCEDURE:
  - Estimate 1999 8hr. Ozone design value for all counties
  - Establish uncertainty field (benchmark – kriged)
    - UAMV modeled 4<sup>th</sup> high 8 hr. average
      - 1996 base emissions
      - 30 days met 1995 – several episodes
  - Weight estimate by uncertainty
    - The larger the residual the less weight the given to the estimate
    - Consider counties with monitors to be considerably more reliable than counties without (to reflect present EPA bias)