


**TOP VIEW**



**SIDE VIEW**

**NOTES**

1. Locate bags in level areas (less than 5% grade). When level areas are not available, place geotextile and coarse aggregate to level the bags.
2. Locate bags in areas approved by the CO. Discharge onto a stable, erosion resistant areas.
3. Locate bags in areas accessible by equipment for maintenance and removal.
4. Insert a maximum of one hose in each bag at any given time.
5. Replace bags when 50% of the sediment capacity has been reached and/or when there is a failure. Have spare bags on site for replacement.
6. Do not cut or empty filter bag onsite. Restore the area according to Subsection 157.15.
7. Do not permit discharge from the bags to drain back into work or access areas of the project.

H:\Team\_Folders\VIDU\6\FP\_14\_Detail\_Review\ALL\_FPI4\_Detail\1570\_Detail.dgn  
 01-Dec-2014 09:33 AM \$TIME\$

NO SCALE

U.S. DEPARTMENT OF TRANSPORTATION FEDERAL HIGHWAY ADMINISTRATION EASTERN FEDERAL LANDS HIGHWAY DIVISION	
U.S. CUSTOMARY DETAIL	
<h3 style="text-align: center;">WATER FILTRATION BAG</h3>	
APPROVED : FEBRUARY 2013 REVISED : NOVEMBER 2014	DETAIL <b>E157-10</b>