



Engineer Research and
Development Center

Documentation and Help for GenCade

Ashley Frey

Research Civil Engineer, Co-PI of the Inlet
Engineering Toolbox work unit of CIRP



**US Army Corps
of Engineers®**



Documentation

■ CIRP Website

The screenshot shows the homepage of the US Army Corps of Engineers Coastal Inlets Research Program (CIRP). The header includes the US Army logo and the program name. Navigation tabs include Home, Products, Publications, Tech Transfer, Wiki, and CIRP. A search bar is present. The main content area features a 'Search the CIRP Website' section with a Google Custom Search box, a 'Latest Additions to the CIRP Webs' section for March 2012, and a 'Full Calendar' for September 2012. A 'CMS v4.0 Fully released' badge is also visible. A sidebar on the right contains a 'Visit the main page' button and a 'Recently Added Publications' section.

<http://cirp.usace.army.mil>

■ CIRP Wiki

The screenshot shows the CIRP Wiki page for the Coastal Inlets Research Program (CIRP) Wiki. The page has a blue header with the CIRP logo and navigation options like 'Page Discussion', 'Read', 'View source', and 'View history'. A search bar is located in the top right. The main content area is titled 'Coastal Inlets Research Program (CIRP) Wiki' and includes a 'CIRP Products' section with a list of tools like CMS, CPT, CSMART, and GenCade. There is also a 'CIRP Publications' section and a 'Recently Added Publications' section. A sidebar on the left contains a 'Visit the main page' button and a 'Recently Added Publications' section.

<http://cirpwiki.info/wiki/CMS>



BUILDING STRONG®



Innovative solutions for a safer, better world

GenCade on CIRP Website



US Army Corps of Engineers
CIRP - Coastal Inlets Research Program

Home Products Publications Tech Transfer Wiki CIRP Search  Find us on Facebook

Bouss-2D CMS CPT / CPT Lite CSMART GenCade Inlet Res. Model (IRM) RMAP SBAS Shoaling Toolbox

SMS Impacts of Inlets on Adjacent Beaches (IIAB) Other Products WaveNet Database

GenCade, Version 1.0

GenCade is a newly developed numerical model which combines the engineering power of GENESIS and the regional processes capability of the Cascade model. GenCade calculates shoreline change, wave-induced long-shore sand transport, and morphology change at inlets on a local to regional scale and can be applied as a planning or engineering tool. GenCade is operated within the Surface-water Modeling System interface, bringing functionality of a georeferenced environment together with accessibility to other U.S. Army Corps of Engineers numerical models. GenCade is being developed jointly by CIRP and the Regional Sediment Management (RSM) program.

GenCade version 1.0 (release)

System Requirements:
[Surface-water Modeling System \(SMS\) version 11.1 beta \(when available\)](#).
For the latest version of SMS 11, see **SMS** tab above.

- [Gencade 1.0](#) [~400 KB zip file] - **updated April 2012.**

Fact Sheet: [GenCade_Version_1 \(PDF\)](#)

Available Documentation:
Documentation is under development. A GenCade User's Guide is in progress and is located on the following wiki page:
<http://cirp.usace.army.mil/wiki/GenCade>.

A Technical Report describing GenCade will be available in Summer 2011.

Principal Point of Contact:
Ashley Frey
Email: Ashley.E.Frey@usace.army.mil

Engineer Research and Development Center
3909 Halls Ferry Road
Vicksburg, MS 39180

BUILDING STRONG.



BUILDING STRONG®



Innovative solutions for a safer, better world

GenCade on CIRP Wiki

Page [Discussion](#) [Read](#) [View source](#) [View history](#)

GenCade

GenCade is a 1D model that combines GENESIS and Cascade. It is operated within the Surface-water Modeling System (SMS) interface. The first official release of GenCade is expected to occur in 2011. A beta version of GenCade is presently available and can be obtained by contacting the POC below. A user guide, examples of simple cases, applications, frequently asked questions, and important information will be posted here. A Technical Report is presently being drafted.

GENESIS + Cascade → GenCade

Cascade (top to bottom)

- Planning tool (RSM Support)
- Time scales: months to centuries
- Multiple inlets, shoals, and barrier islands; cumulative impacts; retains curvature of regional geomorphology
- Fast
- Typical grid resolution ~ 500 m
- Cross-shore processes in future

GENESIS (bottom to top)

- Engineering design tool
- Can represent all engineering details—structures, etc.
- Mature technology – big payback by updating
- Typical grid resolution ~ 25 m

Strategy: Add Cascade capabilities to GENESIS to automatically include all GENESIS features

- Integrate from planning through engineering design
- Cover time scales from days to centuries
- Preserve regional trends
- Furnish regionally consistent boundary conditions to local projects
- Represent cumulative local projects interacting regionally
- Represent inlet bypassing and tidal delta evolution
- Resolve engineered elements
- Include variable grid resolution for accuracy and efficiency
- Improve computational efficiency (over GENESIS)

Figure 1. Combination of GENESIS and Cascade

GenCade was highlighted during two CIRP Workshops in 2011. The first took place in February in Jacksonville, FL. This was the first workshop to include GenCade. About 25 students listened to several GenCade presentations, watched a demonstration, and participated in a hands-on example. A full day session of GenCade was featured in San Diego in August. The next CIRP Workshop is scheduled for March 2012 in Philadelphia. An overview of all CIRP tools, including GenCade, will be given on the first morning. A hands-on session of GenCade will take place during the second afternoon.



GenCade on CIRP Wiki

Documentation

- User Guide
 - Getting Started
 - Preparing Input Files
 - Grid Setup
 - GenCade Files, Menu, Model Setup, and Execution
 - Developing Alternatives
- GenCade Executable
- Input Files
- Output Files
- Parameters
- GenCade Tutorial/Example
- Boundary Conditions
- Wave Input
- GenCade Applications
- Model Calibration
- Technical Documentation
- Frequently Asked Questions



- Main page
- CIRP products
- CIRP publications
- CMS Main Page
- CMS Doc Portal
- GenCade
- Help
- links
 - CIRP Website
 - CHL Website
 - USACE Navigation Gateway
 - Aquaveo Website
- wiki resources
- Toolbox
- Forum Menu
- Print/export

Page Discussion Read View source View history Search

GenCade Users Guide

1. Getting Started

This GenCade guide was last updated in January 2012. Most of the screenshots used in this guide were created with the August 19, 2011, build of the SMS. Developers are constantly upgrading the SMS and GenCade executables, so the graphics in a future version may look slightly different than the visuals included in this user guide.

A very simple example can be found [here](#). This example shows all steps necessary to produce results and includes a zip file with all of the input and output files that can be used to reproduce the results on another computer.

1.1 Setup GenCade in the SMS

GenCade is run within the SMS 11.1 Development. SMS 11.0 and earlier versions do not have interfaces for GenCade. This section will guide a user through the process to set up the conceptual model, convert to a 1D grid, review the GenCade model, run GenCade, visualize results, and develop alternatives. It is assumed that the reader has no previous experience with GenCade.

First, the GenCade executable must be identified on the machine. The GenCade executable will be some variation of GenCade_v1_*.exe. This executable must be placed in the models folder under SMS 11.1. The folder containing SMS 11.1 will most likely be located in Program Files.

Once SMS 11.1 is open on the machine, it is necessary to specify the location of the GenCade executable. If this is specified incorrectly or not at all, GenCade will not run. In order to indicate the location of the executable, it is necessary to click on *Edit*, go to *Preferences*, and click on the tab labeled *File Locations*. The user should scroll down to *GenCade* under *Model Executables* and click on *BROWSE*. Once the GenCade executable is selected, the path for the executable should be listed under *Model Executables* next to *GenCade*. Figure 1 shows the *File Locations* window.

Figure 1. Define GenCade model executable



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

GenCade on CIRP Wiki

Documentation

- User Guide
 - Getting Started
 - Preparing Input Files
 - Grid Setup
 - GenCade Files, Menu, Model Setup, and Execution
 - Developing Alternatives
- GenCade Executable
- Input Files
- Output Files
- Parameters
- GenCade Tutorial/Example
- Boundary Conditions
- Wave Input
- GenCade Applications
- Model Calibration
- Technical Documentation
- Frequently Asked Questions



- Main page
- CIRP products
- CIRP publications
- CMS Main Page
- CMS Doc Portal
- GenCade
- Help
- ▼ links
 - CIRP Website
 - CHL Website
 - USACE Navigation Gateway
 - Aquaveo Website
- wiki resources
- Toolbox
- Forum Menu
- Print/export

Log in / create account

Page Discussion Read View source View history Search

GenCade Input Files

After saving the GenCade project, several files will be created in the user specified folder. These files include *.gen, *.shi, *.shr, *.wave, *.shdx, and *.wl. For example, if the name of the project is test, the input files would be named test.gen, test.shi, test.shr, and test_wave1.wave. In order to run GenCade, at least the *.gen, *.wave, and *.shi files are needed. The *.shr file is necessary for a case with a regional contour, while *.shdx is created when variable grid resolution occurs. The *.wl file is only created when using time-dependent wave transmission for a detached breakwater.

The *.gen file is the control file. The first section of this file lists information about the other input and output files. The first line under files shows the path for the location of the initial shoreline. If the case has a regional contour, the next line will list the location for the regional contour. The next line specifies the number of wave gages included for the simulation while the next lines list the cell of the wave gage, the depth, number of time steps for the wave information, and the path for each wave gage. The next section of the *.gen file is the model setup. This section includes the grid origin and orientation, the simulation start and end date, the time step, the longshore sand transport coefficients (K1 and K2), and the number of cells in the offshore contour smoothing window (ISMOOTH). The next section of the *.gen file is the waves section. This section includes the height amplification factor, angle amplification factor, and angle offset. The D50, berm height, closure depth, and boundary conditions are found under the beach heading. Seawalls, beach fills, inlets, groins, and other features included in the conceptual model follow the beach section in the *.gen file.





Figure 1. Example *.gen - Left panel is top of file

The *.shi file is the initial shoreline data file. Each number in this file represents a cell, and the number is the distance the shoreline is offset for the baseline.



BUILDING STRONG®



Innovative solutions for a safer, better world

Technical Reports and Technical Notes

- Rosati III, J., Frey, A. E., Brown, M. E., and Lin, L. 2011. **Analysis of Dredged Material Placement Alternatives for Bottleneck Removal, Matagorda Ship Channel, Texas.** ERDC/CHL TR-11-2. Vicksburg, MS: U.S. Army Engineer Research and Development Center.
- Thomas, R., and Dunkin, L. 2012. **Erosion Control and Environment Restoration Plan Development, Matagorda County, Texas, Phase 1: Preliminary Investigation.** ERDC/CHL TR-12-11. Vicksburg, MS: U.S. Army Engineer Research and Development Center.
- Beck, T. M., and Legault, K. 2012. **Optimization of Ebb Shoal Mining and Beach Nourishment at St. Johns County, St. Augustine Inlet, Florida.** ERDC/CHL TR-12-14; Report 3. Vicksburg, MS: U.S. Army Engineer Research and Development Center.
- Frey, A.E., Munger, S., Williams, G.L., Wutkowski, M.J., and Conner, K.J. 2012. **GenCade Application at Onslow Bay, North Carolina.** ERDC/CHL CHETN-IV-85. Vicksburg, MS: U.S. Army Engineer Research and Development Center.
- (In printing) Frey, A.E., Connell, K.J., Hanson, H., Larson, M., Thomas, R.C., Munger, S., and Zundel, A. 2012. **GenCade Version 1 Model Theory and User's Guide.** ERDC/CHL TR-12-XX. Vicksburg, MS: U.S. Army Engineer Research and Development Center.



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world